




Model: WRT-805A(66)



Model: WRT-805A(66)



Model: WRT-805A(66)



Switch function

	-65dBV	-40dBV
⊖	ECM-1216MP	GC-0.7MP
⊖	ECM-1222MP	
⊖	ECM-3106MP	
⊖	ECM-448MP	

Settings

1. While holding SET button down, set POWER switch to ON.
2. Press SET button again to select the item (CH, ATT or TIME) to be set.
3. Press +/- buttons to set.
4. To reset the running time display to zero, press 0 button.
5. Set POWER switch to OFF to store the settings.

ICOM® WRT-805A (66)
UHF SYNTHESIZED TRANSMITTER
782.120 - 795.875MHz

NO.

FCC ID :
Icom Corporation Made in Japan

Model: WRT-805A(66)



Model: WRT-805A(66)