


CN200	
1	GND
2	GND
3	CLK
4	DATA
5	LAT
6	RFM
7	LD
8	VCCNT
9	4MHz
10	TXD
11	RXD
12	TEST
13	
14	
15	TONE-OFF
16	ID
17	32.768KHZ
18	LVD
19	AFIND
20	AFM
21	ATT2
22	ATT1
23	ATTO
24	BATTERY
25	BATTERY
26	BAT1
27	POWER-HOLD
28	POFF-IN
29	VCC
30	VCC

LCD ND200	
COM1	13
S0	14
S2	15
S3	16
S4	17
S5	18
S6	19
S7	20
S8	21
S14	22
S15	23
COM0	24
C0	C3
C1	C2
S1	S1
S9	S3
S10	S4
S11	S5
S12	S6
S13	S7
S16	S8
S19	S9
S17	S10
S18	S11
S18	S12
S18	S13
S18	S14
S18	S15
S18	S16
S18	S17
S18	S18
S18	S19
S18	S20

基板名 DP-306 (1/1)
 機種名 : WRT-807FCC 仕向 : F84003710 / F84003711
 Revision : 001 F84003712 / F84003740
 作成者 : F84003741 / F84003750
 更新日 : 1999/02/16
 YYYY/MM/DD HH:MM



MB-860

基板名 MB-860 (1/1)
 機種名 : WRT-B07FCC 仕向 : F84003710 / F84003711
 Rev: 5.101 : 001 F84003712 / F84003740
 作成者 : F84003741 / F84003750
 更新日 : 1999/02/16
 YYY/NN/DD HH:MM

CN-1868

MB-860

CN302				CN303	
1	GND	1	1	GND	1
2	COLD	2	2	COLD	2
3	HOT	3	3	HOT	3
4	ECM-VCC	4	4	ECM-VCC	4
5	GND	5	5	GND	5
6	TEST	6	6	TEST	6
7	TXD	7	7	TXD	7
8	RXD	8	8	RXD	8
9	BATT	9	9	BATT	9
10	BATT	10	10	BATT	10
11	GND	11	11	GND	11
12	GND	12	12	GND	12

MIC

基板名 CN-1868

(1/1)

機種名 : WRT-807FCC 仕向 :

Revision : 001

作成者 :

更新日 : 1999/02/16

YYYY/MM/DD HH:MM

Complete circuit diagram :

< VCO circuit diagram >

