





|       |            |
|-------|------------|
| CN200 |            |
| 1     | GND        |
| 2     | GND        |
| 3     | CLK        |
| 4     | DATA       |
| 5     | LAT        |
| 6     | RFM        |
| 7     | LD         |
| 8     | VCONT      |
| 9     | 4MHz       |
| 10    | TXD        |
| 11    | RXD        |
| 12    | TEST       |
| 13    |            |
| 14    |            |
| 15    | TONE-OFF   |
| 16    | ID         |
| 17    | 32.768KHz  |
| 18    | LVD        |
| 19    | AFIND      |
| 20    | AFM        |
| 21    | ATT2       |
| 22    | ATT1       |
| 23    | ATTO       |
| 24    | BATTERY    |
| 25    | BATTERY    |
| 26    | BAT1       |
| 27    | POWER-HOLD |
| 28    | POFF-IN    |
| 29    | VCC        |
| 30    | VCC        |

|           |    |
|-----------|----|
| LCD ND200 |    |
| COM1      | 13 |
| S0        | 14 |
| S2        | 15 |
| S3        | 16 |
| S4        | 17 |
| S5        | 18 |
| S6        | 19 |
| S7        | 20 |
| S8        | 21 |
| S14       | 22 |
| S15       | 23 |
| COM0      | 24 |
| C1        | 1  |
| C2        | 2  |
| S1        | 3  |
| S9        | 4  |
| S10       | 5  |
| S11       | 6  |
| S12       | 7  |
| S13       | 8  |
| S16       | 9  |
| S19       | 10 |
| S17       | 11 |
| S18       | 12 |
| COM3      |    |



CN-1868



Complete circuit diagram :

< VCO circuit diagram >

