




OVER ALL ASSY

Screw (1 portion For Cover)



Screw (4 portion For Panel Front ASSY )



USB Cable(3pin)


BT ANT

Flexible cable

Panel Front ASSY




Screw (4 portion For Mecha deck)



Bracket Front

Screw (3 portion For Bracket Front )



BT PWB

Screw (2 portion For BT PWB )



BT PWB (A-side)




BT PWB (B-side)

BT transmitter  
CXN1600

# Picture of Bluetooth Transmitter



**TOP**



**Bottom**



**Inside**

**ET101 Shield case**

