




OVER ALL ASSY

Screw (1 portion For Cover)



Screw (2 portion For Panel Front ASSY )




USB Cable(3pin)


Flexible cable

BT ANT cable

Panel Front ASSY




Screw (4 portion For Mecha deck)




Bracket Front

Screw (3 portion For Bracket Front )




Back Cover

Screw (3 portion For Back Cover )





Video PWB Assy

Screw (4 portion For Video PWB Assy)



Screw (2 portion Main PWB Mount Heatshink)

Screw (3 portion Main PWB Mount)




BT transmitter  
CXN1600

# Picture of Bluetooth Transmitter



**TOP**



**Bottom**



**Inside**

**ET101 Shield case**

