

APPENDIX C. INSIDE CONFIGURATION OF EUT

Figure 1
Inside Configuration of the EUT




Figure 2
Inside Configuration of the EUT




Figure 3
Inside Configuration of the EUT




Figure 4
Inside Configuration of the EUT




Figure 5
Inside Configuration of the EUT




Figure 6
Inside Configuration of the EUT




Figure 7
Inside Configuration of the EUT




Figure 8
Battery#1




Figure 9
Battery#1




Figure 10
Battery#1



Figure 11
Battery#2




Figure 12
Battery#2




Figure 13
Battery#2



..... **THE END**