














成品尺寸: 80mm*103mm

材质: 双铜纸 157g

工艺: 风琴折

印刷颜色: 黑白

MULTIPOINT CONNECTION Step 1: Pair the headphones to Device A.  Step 2: Disconnect the headphones from Device A. *7Seven will automatically initiate Bluetooth pairing upon disconnection.  Step 3: Select and pair the headphones to Device B.  Step 4: Reconnect Device A to the headphones to complete Multipoint Pairing. You're now connected to both devices!  <p>6</p>	GAMING MODE While in Bluetooth music mode, press the Multifunction Button four times to activate Gaming Mode . This mode reduces latency for a better gaming experience. To return to Music Mode , press the Multifunction Button four times again.  <p>7</p>	USING THE SECURE FIT LOOP To ensure a snug and stable fit, especially during swimming or vigorous activities, your 7Seven headphones come with a Secure Fit Loop. 1 Insert the two ends of the loop into the connectors on each side of the headband to secure the fit.  2 Adjust the position of the loop to tighten or loosen the fit around the back of your head.  3 Once adjusted, the headphones will sit more securely and comfortably during use.  <p>8</p>	FACTORY RESET • Make sure the headphones are powered off. • Press and hold the Multifunction Button for 10 seconds until the LED flashes red and blue simultaneously 3 times - reset is complete.  <p>9</p>	WARNINGS Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low volume as possible and avoid prolonged use of the earphone/speaker at excessive sound pressure levels. Please read the safety guidelines below prior to using the safety guidelines below prior to using this product. (Prior to using this product follow these steps) 1. Please turn the volume control to its lower level. 2. Then slowly adjust the volume control to a comfortable level. (During the use of this product) 1. Keep the volume at the lowest level as possible. 2. If increased volume is necessary, adjust the volume control slowly. 3. If you experience discomfort or ringing in your ears, immediately discontinue using the product. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort. SAFETY INFORMATION! 1. If you have a cardiac pacemaker or other electronic medical equipment, you should consult your physician before using this product. 2. This product contains small parts that may be hazardous to children. Keep out of the reach of children. The bags themselves or the many small parts they contain may cause choking if ingested. 3. Never attempt to disassemble the product yourself, or push other objects into the device. This may cause a short circuit, which could lead to the fire or get an electric shock. 4. None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. 5. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact your dealer. 6. If the product overheats, is damaged from a fall, or has been exposed to corrosive liquids, please discontinue use. GUARANTEE Jabees is a registered trademark of FreeTek International Co. Ltd. Other brands and product names are trademarks of their respective owners. Jabees warrants this product against all defects in material and workmanship for a period of twelve (12) months from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of Jabees under this guarantee can be read in the Warranty Card. <p>10</p>	REMEMBER Be sure to ensure safe driving, avoid distractions and follow local laws. INFORMATION TO USER FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation. FCC Radio Frequency Exposure Statement The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. <p>11</p>
---	---	---	--	--	---

7  OPEN-EAR BONE CONDUCTION HEADPHONES FOR SWIMMING Quick Reference Guide <p>1</p>	WHAT'S IN THE BOX 7Seven Bone Conduction Headphones x1 Magnetic USB Charging Cable x1   <p>1</p>	PRODUCT OVERVIEW  <ul style="list-style-type: none">① Magnetic Charging Port② LED Indicator Light Charging Red Charging Complete: Blue Pairing: Flash Blue and Red③ Volume +<ul style="list-style-type: none">• Volume +• 1S Next Track④ Multifunction Button<ul style="list-style-type: none">— 3S Power On / Off— Play / Pause— Answer / Hang Up Call— 2S Reject Call— 1S Switch Between Headphones and Phone During a Call• Bluetooth Mode / MP3 Mode— 1S Activate Voice Assistant— 5S Manually Initiate Bluetooth Pairing••••• Gaming Mode / Music Mode⑤ Volume -<ul style="list-style-type: none">• Volume -• 1S Previous Track⑥ Microphone Symbol Notes: <ul style="list-style-type: none">— = Long Press— 1S = Press for 1 Second (The number indicates the duration)• = Press Once•• = Press Twice••• = Press Thrice and so forth. <p>2</p>	CHARGING  Ensure the magnetic charging cable is securely connected to the headphones' charging port before plugging it into a power source.  <p>3</p>	BLUETOOTH MODE  To Power On: Press and hold the Multifunction Button for 3 seconds to turn on the device. It will automatically enter pairing mode.  <p>4</p>	MP3 MODE  Connect the included Magnetic USB Charging Cable to your computer to transfer songs to the 7Seven headphones.  Press and hold the Multifunction Button for 3 seconds to turn on the device.  <p>5</p>
---	---	--	---	---	--