

QUICK START GUIDE

PARTYBOX ENCORE2




WHAT'S IN THE BOX



*Power cord quantity and plug type vary by regions.

BLUETOOTH PAIRING



PLAY



LIGHTSHOW



Apply lightshow presets and more with the JBL PARTYBOX app.


APP




MICROPHONE



GUITAR




MULTI-SPEAKER CONNECTION



CHARGING



MICROPHONE HOLDER



BATTERY REPLACEMENT

1 Remove the Old Battery



2 Insert the New Battery



Change the battery before first use.

