

# QUICK START GUIDE

PARTYBOX ENCORE ESSENTIAL2



HARMAN




## WHAT'S IN THE BOX




\*Power cord quantity and plug type vary by regions.


## BLUETOOTH PAIRING



## PLAY



## LIGHTSHOW



Apply lightshow presets and more with the JBL PARTYBOX app.

## APP




Download and install the JBL PARTYBOX app to get more from the product.



## MICROPHONE



## GUITAR



## MULTI-SPEAKER CONNECTION




## CHARGING



## BATTERY REPLACEMENT

### 1 Remove the Old Battery



### 2 Insert the New Battery



You can purchase a new battery from the JBL Customer Service Center.

## SPLASH PROOF IPX4



Do not charge your speaker until it is completely dry and clean.

