


Block Diagram (75MHz)



Adjustment range

BAND	Frequency	BAND	Frequency
61	75.41MHz	76	75.71MHz
62	75.43MHz	77	75.73MHz
63	75.45MHz	78	75.75MHz
64	75.47MHz	79	75.77MHz
65	75.49MHz	80	75.79MHz
66	75.51MHz	81	75.81MHz
67	75.53MHz	82	75.83MHz
68	75.55MHz	83	75.85MHz
69	75.57MHz	84	75.87MHz
70	75.59MHz	85	75.89MHz
71	75.61MHz	86	75.91MHz
72	75.63MHz	87	75.93MHz
73	75.65MHz	88	75.95MHz
74	75.67MHz	89	75.97MHz
75	75.69MHz	90	75.99MHz