

Here is what you will see on startup.

## Home Screen



### New Design

Start designing with hAppy

### Settings

Adjust settings for using hAppy

### ZINKStore

Go to the store for more elements, designs and hAppy gear

### Library

Go to your Library of elements and designs

### Apps

Launch other apps for use with hAppy

### Help

Handy guide to more hAppy features and tools

## Status Bar



## Autosave

The Design Print Studio will save the design as you work.




All designs are saved in My Designs

## Create these designs to learn


1 Tap once to create a new Canvas for your design.



Type Add some text to your Canvas



Tap to add Text



Enter Text using keyboard


## Tools to Edit Canvas Size

5.50


Tap the screen and type in a new size

2

Choose the height of the label from five sizes



Rotate Elements



Scale Elements

## Zoom



Fit to screen with two modes: fit to width and fit to height



## Completed

### Farmer Joe's

Color change text color



Stamp copy your text



Backdrop add background behind your text



Send Back arrange layers

## Typeface




Choose a typeface


3 Art Add art work to your Canvas



Tap to add Art




Scroll to Browse then Tap to add



Tap on stamp to make a copy

## Stamp



Make a few copies

## Completed



Stamp copy your art



Swap swap an existing art for new art



Send Back arrange layers


4 Photo Add photos to your Canvas



Tap to add a Photo



Scroll to Browse then Tap to add



Tap to crop your photo

## Crop



Crop your photo

## Completed



Crop crop your photo



Swap swap a photo for a new photo




Filter change photo image style


5 Frame Add a Frame to your Canvas



Tap to add a Frame




Scroll to Browse then Tap to add



Tap the Frame weight

## Weight



Slide control the thickness

## Completed



Weight control the weight of the frame



Swap swap a frame for a new frame




Color change text color

6 Print Print Your Design



Tap the Print Button



## Completed

Print press to print your design

Ready to use apply to your project



Instructions  
Follow On-Screen  
②

Please make sure top track matches when inserting.



② Load Your ZR0ll™

Your ZINK Happy+™ should come with the battery partially charged.

and Charge It Up



① Turn ZINK Happy+™ On . . .

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.


**Radiation Exposure Statement:** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

**Note:** The country code selection is for non-US models only and is not available on US models. Per FCC regulation, all WiFi product models marketed in the US must be fixed to US operation channels only.

**BATTERY GUIDELINES AND WARNINGS**

- Don't disassemble the battery.
- Don't short circuit the battery.
- Don't heat or expose the battery to open flame. Heating or exposing the battery to open flame may cause the battery to explode.
- Don't use the battery near heat.
- Don't use the battery near an open fire, oven or any environment where the temperature is above 140°F/60°C.
- Keep the battery dry.
- Don't charge the battery in direct sunlight or in excessive heat.
- Only use the specified power supply when charging the battery.
- Don't physically alter the battery. Don't chip, break, or otherwise damage the battery housing.
- Don't solder the battery. The high temperature of soldering will damage the battery housing.
- Don't connect the battery directly to a main power source or any other improper power supply.
- Don't use the battery in any other devices.
- Don't touch any liquid that may leak from the battery. Electrolyte leakage can be dangerous. If electrolytes come in contact with skin or eyes, immediately flush with water and seek medical assistance.
- Don't store the battery in a pocket or bag together with metallic objects such as keys, jewelry, hairpins, or coins.
- Don't hit the battery with heavy objects such as a hammer or a weight.
- Don't put the battery in a microwave oven, dryer, or high-pressure container.
- Stop charging the battery if charging is not completed within 6 hours.
- Stop using the battery if it becomes too hot to touch or if foul odors are detected.

Contents  
ZINK Happy+™  
1/2" ZR0ll™  
Power Cord  
ZINK Cleaning Roll  
②



The ZINK Happy+™ is the only full color, handheld printer that allows you to design and print beautiful labels, cards, coupons, and more... wherever and whenever you want!



Quick Start