




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3




HIGH CHANNEL 13 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 13 ANT 3

Antenna 4 + Antenna 3 2TX MODE, 26-Tone RU Index 4







LOW CHANNEL 4 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 4 ANT 4




IN-BAND REFERENCE LEVEL ANT 4




OUT-OF-BAND MID CHANNEL ANT 4




HIGH CHANNEL 9 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 9 ANT 4




HIGH CHANNEL 10 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 10 ANT 4




HIGH CHANNEL 11 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 11 ANT 4




HIGH CHANNEL 12 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 12 ANT 4




HIGH CHANNEL 13 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 13 ANT 4




LOW CHANNEL 1 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 1 ANT 3




LOW CHANNEL 2 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 2 ANT 3




LOW CHANNEL 3 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 3 ANT 3




LOW CHANNEL 4 BANDEDGE ANT 3




OUT-OF-BAND LOW CHANNEL 4 ANT 3




IN-BAND REFERENCE LEVEL ANT 3




OUT-OF-BAND MID CHANNEL ANT 3




HIGH CHANNEL 9 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 9 ANT 3




HIGH CHANNEL 10 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 10 ANT 3




HIGH CHANNEL 11 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 11 ANT 3




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3





HIGH CHANNEL 13 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 13 ANT 3

Antenna 4 + Antenna 3 2TX MODE, 26-Tone RU Index 8







LOW CHANNEL 4 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 4 ANT 4




IN-BAND REFERENCE LEVEL ANT 4



OUT-OF-BAND MID CHANNEL ANT 4



HIGH CHANNEL 9 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 9 ANT 4