


12. SETUP PHOTOS

ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP




RADIATED RF MEASUREMENT SETUP (BELOW 1 GHz)



RADIATED FRONT PHOTO (BELOW 1 GHz)



RADIATED BACK PHOTO (BELOW 1 GHz)




RADIATED RF MEASUREMENT SETUP FOR PORTABLE CONFIGURATION





Y-AXIS FRONT PHOTO



Y-AXIS BACK PHOTO






POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP

EUT POWERED BY AC/DC ADAPTER

LINE CONDUCTED FRONT PHOTO





LINE CONDUCTED BACK PHOTO



DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

STANDARD CLIENT MODE



CLIENT TO CLIENT MODE


DFS FRONT PHOTO (EUT)



DFS BACK PHOTO (EUT)



FULL SETUP



END OF REPORT

Page 907 of 907