A2068, A2230,A2231

Front - Multi-Touch display,
Front camera

A2068, A2230,A2231

Back - Microphone, Rear camera, Smart connector

A2068, A2230,A2231

Top Side - Sleep/Wake button, Microphones, Speakers

A2068, A2230,A2231

Bottom Side - USB-C adapter, Speakers



A2068, A2230,A2231

Left Side- Microphone



A2068, A2230,A2231

Right Side - Volume up/down buttons,
Wireless Charger for pencil, Sim tray