

A3143

Top



A3143  
Bottom



A3143

Front - Status Light Indicator,  
SD Card Slot, Two USB-C Ports




A3143

Rear - Power Button, Headphone Jack,  
HDMI Port, Two USB-A Ports, A/C Inlet,  
Gigabit Ethernet Port, Four USB-C Ports



**A3143**

Left



A3143

Right

