


A3267, A3270

Front: Multi-Touch Display,
Front Camera




A3267, A3270

Back Housing: Rear Camera, Microphone, Smart Connector




A3267, A3270


Right Side: Wireless Charger for Pencil, Volume Up/
Down Buttons



A3267, A3270
Top Side: Power/Sleep/Wake Button, Speakers



A3267, A3270
Left Side



A3267, A3270
Bottom Side: USB-C Connector, Speakers

