


A3268

Front: Multi-Touch Display, Front Camera



A3268

Back Housing: Rear Camera,
Microphone, Smart Connector



A3268

Top Side: Power/Sleep/Wake Button, Speakers




A3268
Left Side



A3268

Right Side: Wireless Charger for Pencil, Volume Up/
Down Buttons



A3268

Bottom Side: USB-C Connector, Speakers

