Statement

1. This equipment complies with FCC RF radiation exposure Limits set forth for an uncondrolled environment.

2. This device complies with part 15 of the FCC rules. Operation is subject to the follwing two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

3. This equipment is portable device. The output power of this device is less than 20mW. The SAR test is not required.

4. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

5. Ce dispositif doit être installé et exploité dans une enceinte entièrement fermée afin de prévenir les rayonnements RF qui pourraient autrement perturber la navigation aéronautique.

L'installation doit être effectuée par des installateurs qualifiés, en pleine conformité avec les instructions du fabricant.

6. Ce dispositif ne peut être exploité qu'en régime de non-brouillage et de non-protection,


c'est-à-dire que l'utilisateur doit accepter que des radars de haute puissance de la même bande

de fréquences puissent brouiller ce dispositif ou même l'endommager. D'autre part, les capteurs

de niveau à propos desquels il est démontré qu'ils perturbent une exploitation autorisée par

licence de fonctionnement principal doivent être enlevés aux frais de leur utilisateur.

DO NOT USE
HAND HOLD
WHEN CANOPY
DOORS ARE




A5Ø HEADSET & MIXAMP™ QUICK START GUIDE









MixAmp™ Tx

Mic Down: On

A50 STAND & MIC

POWER / PAIRING & CHARGING

Solid Red On / Full Power / USB Powered

Blink Red + Audible Beep Low Power / Charge Immediately

Solid Orange Charging Li-Ion Battery

A50 and Tx come pre-paired. Do not initiate pairing

1. Begin pairing mode by holding ! the power button on Tx until it blinks white.

2. Hold A power button on A50 until it also blinks white and then release, ASO is now in pairing mode.

3. Pairing is confirmed 4. When pairing is by both devices when complete, both A50 LEDs are solid white & Tx power buttons for 3 seconds. will turn red.







XBOX LIVE® CABLE -

[connect to controller for XBOX Live® Chat]

USB POWER CABLE (1m) -

OPTICAL CABLE -[connect for high quality audio]

USB CHARGING CABLE (.5m) -(connect to charge A50 Headset)

A50 USE ENVIRONMENT

Use Temberature: 0°C-40°C

Input Voltage: 5V Input Current: 0.5A

MIXAMPTM TX USE ENVIRONMENT

Use Temberature: 0℃-40℃

Input Voltage: 5V Input Current: 0.5A Output Voltage: 5V Output Current: 0.5A XBOX 360 SETUP





PS3 SETUP



For Game Audio

- . Ga to Settings > Sound Settings > Audio Output
- Settings
 Choose "Optical Digital" and DNLY activate "Dolby Digital 5.1 Ch" Make sure that "DTS 5.1 Ch" is NOT selected

For Voice Chat

- Go to Settings > Accessory Settings > Audio
- Device Settings
 Under both "Input Device" and "Output Device", select "ASTRO WIRELESS TRANSMITTER"

PC SETUP



- For Same Audio on PC using Windows 7 Pro
 Go to Control Panel > Sound > Playback
 Select "SPDIF Out" or your digital output, then
- "Set as Default Device"
- For Voice Chat

 Go to Control Panel > Sound > Recording

 Select "ASTRO WIRELESS TRANSMITTER", then
- "Set as Default Device"

To guarantee full functionality, be sure your sound card supports "Dolby Digital" technology

STAND ASSEMBLY



For additional setup scenarios, download our full users guide at www.astrogaming.com/support/manuals

@ 2012 ASTRO GAMING