

TABLE OF CONTENTS**CHAPTER 1 ID LABEL/LOCATION INFO**

1.1 Rear Panel FCC Label	1-1
1.2 Rear Panel Manufacturer's Label	1-1
1.3 Rear view, complete Axcera-5721 Transmitter w/FCC and Manuf. Label	1-2

CHAPTER 2 EXTERNAL PHOTOS

2.1 Front view, complete Axcera-5721 Transmitter w/ Mod. (Front Panel Up) ..	2-1
2.2 Front view, complete Axcera-5721 Transmitter w/ Mod. (Front Panel Down)	2-1
2.3 Rear view, complete Axcera-5721 Transmitter w/ QAM Modulator.....	2-2
2.4 Front view, Sagem QAM Modulator, Model PQM 2100	2-2
2.5 Rear view, Sagem QAM Modulator, Model PQM 2100	2-2
2.6 Front view, Channel Filter	2-3

CHAPTER 3 SCHEMATICS**CHAPTER 4 TEST REPORT**

4.1 RF Power Measurements	4-1
4.2 Modulation Characteristics	4-2
4.3 Occupied Bandwidth	4-3
4.4 Conducted Spurious Emissions	4-4
4.5 Radiated Emissions	4-10
4.6 Frequency Stability	4-12
4.7 Test Equipment	4-14

CHAPTER 5 USER'S MANUAL**CHAPTER 6 INTERNAL PHOTOS**

6.1 Front view, Chassis Assembly	6-1
6.2 Side view, IF Processor Assembly	6-1
6.3 Side view, Control Monitoring Assembly	6-2
6.4 Side view, L.O./Upconverter Assembly	6-2
6.5 Side view, Power Supply Assembly	6-3
6.6 Top view, Power Amplifier Assembly	6-3

CHAPTER 7 PARTS LIST/TUNE-UP INFO

7.1 Parts List	7-1
7.2 Tune-up Information	7-1
7.2.1 QAM Modulator	7-1
7.2.2 Upconverter/Assembly	7-1
7.2.2.1 Control Monitoring Assembly	7-1
7.2.2.2 IF Processor Assembly	7-2
7.2.2.3 L.O. / Upconverter Assembly	7-2
7.2.2.4 Power Amplifier Assembly	7-2
7.2.2.5 Power Supply Assembly	7-2
7.2.3 Power Set-up / Meter Calibration	7-2
7.2.4 RF Response	7-3

CHAPTER 8 OPERATIONAL DESCRIPTION - MODEL Axcera-5721

8.1 General Description	8-1
8.2 Technical Specifications.....	8-1
8.3 Performance Specifications	8-1
8.4 System Overview	8-3
8.4.1 QAM Modulator - Upconverter/Amplifier Tray	8-3
8.4.1.1 IF Processing Assembly	8-3
8.4.1.2 L.O./Upconverter Assembly	8-4
8.4.1.3 Power Amplifier Assembly	8-5
8.4.1.4 Control/Monitoring Assembly	8-6
8.4.1.5 Power Supply Assembly.....	8-6
8.5 Control and Status	8-8
8.5.1 Upconverter/Amplifier Tray.....	8-8
8.6 Input and Remote Connections	8-10
8.6.1 Remote Interface Connections (Upconverter/Amplifier Tray)	8-10
8.7 AC Input	8-10
8.7.1 Upconverter/Amplifier Tray.....	8-10
8.8 System Operation	8-10
8.8.1 Principles of Operation	8-11

CHAPTER 9 CERTIFICATION OF TEST DATA

Trak Systems Model 8821 Datasheet.....	Sheet 1, Sheet 2
--	------------------