

Venue 8
7000 Series


Quick Start Guide

Translated Text Here
Translated Text Here
Translated Text Here
Translated Text Here




1 Connect the power cable and press the power button for 2 seconds

Connect the power cable and press the power button for 2 seconds
Connect the power cable and press the power button for 2 seconds
Connect the power cable and press the power button for 2 seconds
Connect the power cable and press the power button for 2 seconds




2 Finish Android setup

Finish Android setup | Finish Android setup
Finish Android setup | Finish Android setup



Connect to your network.
Connect to your network.
Connect to your network.
Connect to your network.



Sign in to your account or create a new account.
Sign in to your account or create a new account.
Sign in to your account or create a new account.
Sign in to your account or create a new account.


3 Register your tablet

Register your tablet | Register your tablet
Register your tablet | Register your tablet

dell.com/support/retail


Inserting microSD card (optional)

Inserting microSD card (optional)
Inserting microSD card (optional)
Inserting microSD card (optional)
Inserting microSD card (optional)



Inserting SIM card (on LTE/HSPA+ models only)

Insert SIM card (on LTE/HSPA+ models only)
Insert SIM card (on LTE/HSPA+ models only)
Insert SIM card (on LTE/HSPA+ models only)
Insert SIM card (on LTE/HSPA+ models only)



Product support and manuals

Product support and manuals
Product support and manuals
Product support and manuals

Contact Dell

Contact Dell | Contact Dell
Contact Dell | Contact Dell

Regulatory and safety

Regulatory and safety | Regulatory and safety
Regulatory and safety | Regulatory and safety

Regulatory model and type

Regulatory model and type
Regulatory model and type
Regulatory model and type
Regulatory model and type

Tablet model

Tablet model | Tablet model
Tablet model | Tablet model

dell.com/support

dell.com/support/manuals

dell.com/contactdell

dell.com/regulatory_compliance



T02E

T02E001

Venue 8 7840

Features

Features | Features | Features | Features



1. Ambient-light sensor
2. Front camera
3. Speaker
4. Audio port
5. Micro-USB port
6. Microphone
7. Volume button

8. Power button
9. 3D camera (2)
10. Rear camera
11. MicroSD-card slot
12. SIM-card slot (LTE/HSPA+ models only)
13. Charging pads

1. Ambient-light sensor
 2. Front camera
 3. Speaker
 4. Audio port
 5. Micro-USB port
 6. Microphone
 7. Volume button
8. Power button
 9. 3D camera (2)
 10. Rear camera
 11. MicroSD-card slot
 12. SIM-card slot (LTE/HSPA+ models only)
 13. Charging pads

1. Ambient-light sensor
2. Front camera
3. Speaker
4. Audio port
5. Micro-USB port
6. Microphone
7. Volume button

8. Power button
9. 3D camera (2)
10. Rear camera
11. MicroSD-card slot
12. SIM-card slot (LTE/HSPA+ models only)
13. Charging pads

1. Ambient-light sensor
 2. Front camera
 3. Speaker
 4. Audio port
 5. Micro-USB port
 6. Microphone
 7. Volume button
8. Power button
 9. 3D camera (2)
 10. Rear camera
 11. MicroSD-card slot
 12. SIM-card slot (LTE/HSPA+ models only)
 13. Charging pads

