

Quick Start

Quick Start

Regulatory Model/Type

Venue 10

T13G / T13G001





Read the safety information that shipped with your computer. For additional safety best practices information, see the Regulatory Compliance Homepage at www.dell.com/regulatory_compliance.



Do not remove the computer cover unless you need to install internal accessories for your computer. For instructions on removing and replacing parts, see the *Owner's Manual* at dell.com/support.



Retain the filler brackets or cards that ship with your computer. Installing filler brackets or filler cards over empty card-slot openings is necessary to maintain FCC certification of the computer. The filler brackets and filler cards keep dust and dirt out of your computer and maintain the airflow that cools your computer.

Power Adapter

Input voltage



Input current (maximum)

Input frequency


Output current

Output voltage


Connect the power adapter or the power cable to your computer and to the display, if required.



Connect the network cable (optional).



Power on the computer (and the display, if connected).






Depending on your computer configuration, some ports or connectors may not be available.

Icons

Power adapter



USB



USB with PowerShare



eSATA

eSATA

Thunderbolt



Network



VGA



DVI



HDMI

HDMI

DisplayPort



Mini DisplayPort



TV-in



Infrared (IR) emitter



Headphone/Audio-out



Icons

Headset/Audio-out	
Microphone	  
Line-in	
Line-out/Speakers: front left-right	
Speakers: rear left-right	
Speakers: side left-right	
Speakers: Audio center/subwoofer	
S/P DIF	S/P DIF
Screen-rotation lock	
SIM-card slot	
ExpressCard slot	EC
Media-card reader	     MMC.SD.MS/PRO
Security-cable slot	  
Power/Battery-status light	

Icons

Battery-status light



Hard-drive activity light



Wi-Fi light



Bluetooth light

