



(17) EUT Photo




(18) EUT Photo



(19) EUT Photo




(20) EUT Photo




Mode 1& Mode 4 (FAIRWAY Adapter)
(21) EUT Photo




(22) EUT Photo




(23) EUT Photo



Mode 2 & Mode 3 (LI-SHIN Adapter)
(24) EUT Photo




(25) EUT Photo



(26) EUT Photo



(27) EUT Photo



(28) EUT Photo (1394 Card)



(29) EUT Photo (1394 Card)

