


XX-B55 IB (Generic IB For AV/FD/FR/PW-B55) (apply IC)
(Front)
Size: 180 x 230 mm
Color: black text on white paper (1C + 1C)

Date: Jan. 12, 2016



Important Message to Consumers

Thank you for purchasing one of our many top-quality electronic products. Please take a moment to read through these instructions to help you understand the safe and proper way to use this product to extend its usability. Keep these instructions for future reference as they contain important information.

FCC & IC Information

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible or compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :


- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Using Your Speaker



Turning the Speaker ON/OFF

Press and hold the **Power Button** for approximately 2 seconds to turn the speaker ON or OFF. When the speaker is ON, press and release the button to play or pause the audio.

USB Charging Port

To charge the speaker, connect the included micro USB cable to the **Charging Port** on the side of the speaker. (See reverse side of manual for detailed charging instructions.)

Reset Button

Quickly press the **Reset Button** to reset the speaker.

Bluetooth Pairing Button

See reverse side of manual for detailed Bluetooth pairing instructions.

XX-B55 IB (Generic IB For AV/FD/FR/PW-B55) (apply IC)
(Back)




Using Bluetooth with the B55

1. Make sure your Bluetooth device and the B55 speaker are fully charged. Turn on your Bluetooth device and make it 'discoverable' by turning on Bluetooth mode (check in Options or Settings).
2. When the B55 speaker is ON, press and hold the **Bluetooth Pairing Button** until you hear a confirmation tone. The LED will flash blue as the speaker attempts to pair with a Bluetooth device.
3. "eKids B55" should appear on your device. If "Not Connected" or similar message appears, select "eKids B55" to connect.
4. Once paired, the blue LED will glow solid. You can then stream audio to the speaker, and control the music from your Bluetooth device. Remember to turn off the speaker and your device after listening.

Note: If no device is paired within 5 minutes, the speaker will automatically shut off. To retry pairing, repeat steps 1-4 above.

Charging the B55

To charge the speaker, connect the included micro USB cable to the **Charging Port** on the side of the speaker. Connect the standard USB plug to a computer, USB AC adapter (not included) or other USB power source. The red LED will light up while the speaker charges, and will automatically shut off when charging is complete.



Questions or Comments

☎ For questions or comments regarding this or other eKids products, please call our toll-free number: 1-888-TOP-TOYS.

Please also visit our website: www.ekids.com

Limited 90 Day Warranty

eKids warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, eKids will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service. If service is required, please call Customer Service at 1-888-TOP-TOYS (1-888-867-8697) to obtain a Return Authorization Number and shipping instructions.

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or wilful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will eKids or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your eKids product.

Distributed by eKids, LLC
For questions or comments please call our toll-free number: **1-888-TOP-TOYS**
Also visit our website: **www.ekids.com**
1299 Main Street Rahway, NJ 07065