



Overview

Parent Unit



Baby Unit



Parent Unit icons

Main Menu Icons

| | |
|--|-------------------------------------|
| | Temperature |
| | Brightness |
| | Lullaby |
| | Camera settings |
| | Monitoring mode (For LF2414-2 only) |
| | Night Light |
| | Status icon |
| | Screen off Timer |
| | FCC and IC regulations |
| | Alert settings |

| | |
|--|--|
| | Turn on/off temperature Alert. |
| | Adjusts the parent unit LCD screen brightness. |
| | Select the minimum and maximum temperature range. |
| | Temperature display format. |
| | Play/Stop |
| | Select to play one of the four soothing sounds. |
| | Select to play one of the five melodies or play all. |
| | Zoom |
| | Select a camera to view. |
| | View in Patrol mode. |
| | View in Split mode. |

The RBRC seal



The RBRC seal on the Li-ion battery indicates that VTech Communications, Inc. is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States and Canada. The program provides a convenient alternative to placing used Li-ion batteries into the trash or municipal waste, which may be illegal in your area. VTech's participation makes it easy for you to drop off the spent battery at local retailers participating in the program or at authorized VTech product service centers. Please call 1 (800) 8 BATTERY for information on Li-ion battery recycling and disposal bans/restrictions in your area. VTech's involvement in this program is part of its commitment to protecting our environment and conserving natural resources. The RBRC Seal and 1 (800) 8 BATTERY® are registered trademarks of Call2Recycle, Inc.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander, according to FCC rules, for the product. The Baby Unit has been tested and found to comply with FCC criteria.

The Baby Unit shall be installed and used such that all persons' body are maintained at a distance of approximately 8 in (20 cm) or more. The transmitter and antenna of the Parent Unit shall be held at least in (25 cm) from your face.

This Class B digital apparatus complies with Canadian requirement: CAN ICES-3 (B)/NMB-3(B)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

RF radiation exposure statement

The product complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The Baby Unit should be installed and used such that a distance of at least 20 cm between the Baby Unit and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of Humans to RF Fields.

RF radiation exposure statement

The product complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. The Baby Unit should be installed and used such that a distance of at least 20 cm between the Baby Unit and all persons' body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. This equipment complies also with Industry Canada RSS-102 with respect to Canada's Health Code 6 for Exposure of Humans to RF Fields.

20 Vous devriez tester la réception chaque fois que vous mettez l'appareil en fonction.

21 Evitez les composantes afin de vérifier si celles-ci ne sont pas endommagées.

22 Il existe un très faible risque de perte de confidentialité avec certains appareils électroniques (autres écouteurs-bébés, téléphones sans fil etc.). Pour l'éviter, à assurer que le produit n'a jamais été utilisé avant l'achat, réinitialiser l'unité de façon périodique, éteindre l'écoute-bébé quand il n'est pas en cours d'utilisation.

23 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

24 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

25 Le produit n'est pas conçu pour être utilisé des personnes (y compris des enfants) avec des handicaps physiques, mentaux ou sensoriels qui manquent d'expérience et de connaissances à moins qu'ils aient donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.

CONSERVEZ CES INSTRUCTIONS

Mises en garde

1 Utilisez et entreposez le produit à une température entre 0°C (32°F) et 40°C (104°F).

2 N'exposez pas cet appareil à des froids ou des chaleurs extrêmes, ainsi qu'à la lumière directe du soleil. Ne l'installez pas près d'une source de chaleur.

3 Le bloc-pile ne doit pas être exposé à la chaleur excessive telle que la lumière du soleil ou au feu.

4 Risque de brûlure, risque d'incendie, risque d'explosion associé à une mauvaise manipulation de piles.

5 Avertissement-Risque de strangulation-Les enfants se sont ENTRANGLÉS dans des cordons. Gardez ce cordon hors de portée des enfants (à plus de 0,9 m). N'enlevez PAS cette étiquette.

6 Ne jamais placez le moniteur à l'intérieur du berceau ou du parc de bébé. Ne jamais couvrir le moniteur ou l'unité (s) portative avec un article tel une serviette ou une couverture.

7 D'autres équipements et éléments peuvent produire des interférences avec votre moniteur vidéo ou audio. Tenter d'installez votre moniteur vidéo ou audio à l'écart des appareils électriques tels que des routeurs sans fil, radios, téléphones cellulaires, interphones, moniteurs, téléphones, ordinateurs personnels, électroménagers et téléphones portables.

8 Utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril.

9 Utilisez que les adaptateurs inclus avec ce produit. L'utilisation d'un adaptateur dont la polarité ou la tension serait inadéquate risque d'endommager sérieusement le produit et mettre votre sécurité en péril.

10 Pour les PRODUITS À BRANCHER À UNE PRISE DE COURANT, la prise de courant doit être installée près du produit, afin d'assurer une sécurité supplémentaire à la prise de courant.

11 Débranchez ce produit de la prise de courant avant de procéder au nettoyage. N'utilisez pas de nettoyeurs à aérosols. Utilisez un chiffon humide pour le nettoyage.

12 Pour les PRODUITS À BRANCHER À UNE PRISE DE COURANT, la prise de courant doit être installée près du produit, afin d'assurer une sécurité supplémentaire à la prise de courant.

13 Ne laissez aucun objet reposer ni appuyer sur le cordon d'alimentation ou le câble de la télécommande.

14 N'installez pas cet appareil dans un endroit où l'on risque d'écraser le cordon d'alimentation ou de le piétre.

15 Ne surchargez pas les prises de courant murales ni les rallonges électriques.

16 Ne placez pas cet appareil sur un chariot, meuble, trépied, support de montage ni table chancelante.

17 Les trous et ouvertures du boîtier, situés à l'arrière de l'appareil doivent être gardés propres pour assurer la ventilation correcte. Ne les bouchez pas, ne bloquez pas aucunes ouvertures et n'empêchez pas l'aération adéquate de l'appareil en le placant sur un lit, divan, tapis ou toute autre surface similaire. De même ne le positionnez pas à proximité ou au-dessus d'une source de chaleur ou d'un calorifère. De plus, ne placez pas l'appareil dans un endroit avant de vous assurer qu'il y a une bonne circulation d'air.

18 Ne placez pas l'appareil dans un endroit où il peut être soumis à des vibrations ou des chocs.

19 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

20 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

21 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

22 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

23 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

24 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

25 Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide. Ne laissez pas les piles ou les batteries sortir de l'appareil.

Online Manual

QR code

leapfrog.com/support

Find the answer to your question on our knowledge-rich Online Manual. Get assisted at your own pace and learn what your monitor is capable of.

Scan the QR code to access the Online Manual or visit leapfrog.com/support

For cETL compliance only

Measures de sécurité importantes

La plaque signalétique appliquée est située au bas du socle de l'appareil.

Lorsque vous utilisez votre appareil, vous devriez toujours suivre certaines mesures de précaution de base afin de réduire les risques d'incendie, d'électrocution et de blessures corporelles, dont ceux qui suivent :

1. Observez toutes les instructions et mises en garde inscrites sur l'appareil.

2. L'installation par un adulte est requise.

3. Evitez les composantes afin de vérifier si celles-ci ne sont pas endommagées.

4. Il existe un très faible risque de perte de confidentialité avec certains appareils électroniques (autres écouteurs-bébés, téléphones sans fil etc.). Pour l'éviter, à assurer que le produit n'a jamais été utilisé avant l'achat, réinitialiser l'unité de façon périodique, éteindre l'écoute-bébé quand il n'est pas en cours d'utilisation.

5. Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide.

6. Afin de réduire les risques d'électrocution, ne démontez pas cet appareil, ne laissez pas appuyer dans l'eau et ne le placez pas sur une surface chaude ou humide.

7. Le produit n'est pas conçu pour être utilisé des personnes (y compris des enfants) avec des handicaps physiques, mentaux ou sensoriels qui manquent d'expérience et de connaissances à moins qu'ils aient donné suffisamment de supervision ou d'instructions relativement à l'utilisation de l'appareil par une personne responsable de leur sécurité.

8. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

9. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

10. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

11. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

12. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

13. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

14. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

15. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

16. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

17. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

18. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. LeapFrog and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss.

19. LeapFrog et ses fournisseurs assume no responsibility for any damage or loss resulting from the use of this handbook. LeapFrog and its suppliers assume no responsibility for any loss