


AirStation Quick Setup Guide


2015-01

Setup



Default Values


WXR-1900DHPD



The setup card for the WSR-1166DD/WSR-600DD is included in the package.


Opening Settings

- 1




192.168.11.1

192.168.11.1
- 2



password
- 3




Router Info	Release	DD-WRT NG beta r0.8.1
	Hardware	Buffalo WXR-1900DHP
	Kernel version	3.10.49
	Uptime	01:24:17
	Current time	12/01/2015 04:31:05
	Current load	0.90/0.115/0.104
	Memory usage	43/503 MB
Internet Connection	Wan Port	Connecting
Wireless Network	SSID (2.4 GHz)	Buffalo-G-4E1E
	SSID (5 GHz)	Buffalo-A-4E1E


Note: After logging in to Settings, we recommend that you change the default administrator password.

LEDs

WXR-1900DHPD



WSR-1166DD



Technical Support

Buffalo Americas
www.buffaloamericas.com

DD-WRT
www.dd-wrt.com

DD-WRT Forum
www.dd-wrt.com/phpBB2

WSR-600DD

