



Figure 5.1. Transmitter on the test table (Open-Site). The transmitter is tested when placed flat, on a side and on an end.  
 (top) Orientation of the transmitter for maximum emission  
 (bottom) Close-up (M-51)