

BATTERY REPLACEMENT


REMOVE SCREW TO OPEN BATTERY COMPARTMENT COVER. EACH UNIT REQUIRES 1-9V 3ATTERY (NOT INCLUDED). REPLACERATTERY COMPARIMENT COVER AND SCREW ALKALINE BATTERIES ARE RECOMMENDED FOR BEST PERFORMANCE DO NOT NIX OLD AND NEW BATTERIES.

DO NOT NIX ALKALINE STANDARD (CARRON-ZNC) OR RECHARGEARLE (NICKEL-CADMILIM) RATTERIES NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED

BATTERIES ARE TO BE INSEFTED WITH THE CORRECT POLARITY EXHAUSTED BATTERIES ARETO BE REMOVED FROM THE TOY

THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOYBEFORE BEING CHARGED RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ABULT SUPERVISION.

ONLY BATTERIES OF THE SAVE OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLOTE OR LEAK



ANTENNA

TO OPERATE

- 1. Switch the ON/OFF VOLUME control ON by sliding
- 2. To transmit, press the 'PUSH TO TALK' button with the microphone about 4" from your mouth. Speak in a normal voice.
- 3. To receive, release the 'PUSH TO TALK' button.
- 4. After you have finished using the walkie talkie switch the ON/OFF volume control OFF by sliding the control downward

CAUTION:

- 1. If your walkie talkie does not operate properly try a new set of batteries since your batteries may be defective or have low voltage even though they appear to be new.
- 2. After use always return the ON/OFF control switch to the OFF position.
- 3. Do not touch antenna with your fingers or hand. It will cause weak transmission.
- 4. Your walkie talkie set has been fully adjusted prior to shipment from the factory. Do not touch the nternal parts other than replacing the battery.
- 5. Manufacturer recommends alkaline patteries for maximum performance.
- 6. To prevent damage. Do not expose the set to rain or
- 7. Modifications not authorized by the manufacturer should not be made.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC BUILES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMEUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION. NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THE EQUIPMENT SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: THIS FOLLIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS B DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE IN A RESIDENTAL INSTALLATION. THIS EQUIPMENT GENERATES, USES AND CAN RADIALE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTIONS, MAY CAUSE HARMFUL INTERFERENCE TO BADIO COMMUNICATIONS. HOWEVER THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN A PARTICULAR INSTALLATION IF THIS FOLIPMENT DOES CAUSE HARMFUL INTERFRENCE TO RADIO OR TELEVISION RECEPTION. WHICH CAN BE DETERMINED BY TURNING THE EQUIPMENT OFF AND ON THE USER IS ENCOURAGED TO TRY TO CORRECT THE INTERFERENCE BY ONE OR MORE OF THE FOLLOWING MEASURES

- REORIENT OR RELOCATE THE RECEIVING ANTENNE.
- INCREASE THE SEPARATION BETWEEN THE FOLIEMENT AND RECEIVER
- CONNECT THE EQUIPMENT INTO AN OUTLET ON A CIRCUIT DIFFERENT FROM THAT TO WHICH THE RECEIVER IS CONNECTED.
- CONSULT THE DEALER OR AN EXPERIENCE BADIC/TV TECHNICIAN FOR HELP

KAWASAKI® IS A TRADEMARK LICENSED BY KAWASAKI MOTORS CORP., U.S.A., WHICH DOES NOT MANUFACTURE OR DISTRIBUTE THIS PRODUCT. CONSUMER INCLURES SHOULD BE DIRECTED TO KIDZ TOYZ, INC., 280 NORTH BEDFORD ROAD. SUITE 203, MT. KISCO, NEW YORK 10549 USA

because kidz like toyz KIDZ TOYZ, INC. MT. KISCO, N.Y. 10549

For Product Questions. Call 1-877-KIDZTOY (877-543-9869) Ask for CUSTOMER SERVICE. Only in the U.S. and CANADA

Please visit us on the web at: www.kidztoyz.com ITEM NO. 22270

MADE IN CHINA