



# GARMIN DASH CAM™ MINI 3



GARMIN®

## 2

Set Up • Configuration • Configurazione • Einrichtung • Configurar

[garmin.com/driveapp](https://garmin.com/driveapp)



• Manuals • Videos • Support • Regulatory Information • Manuels • Vidéos • Assistance • Informations réglementaires • Manuali • Video • Assistenza • Informazioni sulle normative • Handbücher • Videos • Support • Aufsichtsrechtliche Informationen • Manuales • Vídeos • Asistencia • Información sobre las normativas vigentes



[garmin.com/manuals/DashCamMini3](https://garmin.com/manuals/DashCamMini3)



[garmin.com/videos/DashCamMini3-gettingstarted](https://garmin.com/videos/DashCamMini3-gettingstarted)

[support.garmin.com](https://support.garmin.com)

© 2024 Garmin Ltd. or its subsidiaries

Garmin® and the Garmin logo are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Dash Cam™ is a trademark of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

The microSD™ logo is a trademark of SD-3C, LLC.

2.4 GHz @ 19.8 dBm maximum




Printed in Taiwan  
June 2024  
I90-03124-01\_0A






# 1

## Installation • Installation • Installazione • Installation • Instalación



\*Class 10 microSD™ card not included \*Carte microSD™ de classe 10 non incluse  
 \*Scheda microSD™ di classe 10 non inclusa \*microSD-Karte der Klasse 10 nicht im Lieferumfang enthalten  
 \*Tarjeta microSD™ de clase 10 no incluida




**TIP:** To hide the power cable, route it behind the vehicle trim along the windshield, doorframe, or dash.

**ASTUCE :** pour masquer le câble d'alimentation, faites-le passer sous le ciel de toit le long du pare-brise, de la portière ou du tableau de bord.

**SUGGERIMENTO:** per nascondere il cavo, è opportuno passarlo dietro le finiture dell'abitacolo lungo il parabrezza, lo sportello o il cruscotto.

**TIPP:** Verlegen Sie das Netzkabel hinter der Verkleidung des Fahrzeugs entlang der Windschutzscheibe, des Türrahmens oder des Armaturenbretts, damit es nicht zu sehen ist.

**CONSEJO:** Para ocultar el cable de alimentación, colócalo por la moldura del parabrisas, el marco de la puerta o el salpicadero.



## Format microSD™ Card • Formater la carte microSD • Formatta scheda microSD microSD-Karte formatieren • Transferencia de datos

