

Making a Call

1. Press the Phone number you want to call.
2. You will hear the phone call on the radio.
3. If there is music playing on your phone, you will listen to the music again after phone call disconnected.

Voice Calling

If your phone supports voice dialing, and it is activated, you can use this feature with this portable handsfree.

1. Press the "Phone button".
2. Wait for tone that indicates you can say the name as you recorded on your phone.

Factors affecting the Sound Quality

-Sound setting in the phone

Recommended : Set the volume level to 80% and the equalizer option to Normal

-Solid objects between the transmitter and the antenna of the receiver

-Transmission on the similar frequencies.

-The major feature is designed to transmit your music phone's tune to FM radio. It is capable of transmitting phone call's voice signal to FM radio, but the radio's sound quality may be interfered by the mobile phone while receiving or making a call

Recommended : Please turn down volume to acceptable level. If situation continue to exist, please turn off the FM Transmitter and use your portable handsfree.

Important Information!

Follow regional guidelines/legislation for use of FM-radio transmitters

Instruction to the user

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This user is cautioned the changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.