

# USER MANUAL

## GENERAL (NOT FOR FIELD REPRESENTATIVE'USE):

Each lamp is provided with an Edison medium type lamp base for connection to a 110-120v source of supply through medium base lampholder.

### **SUPPLY VOLTAGE:**

110-120V, 60HZ

### **Note:**

1. Be known as a none-user replaceable lamp and a self-ballasted lamp.
2. With a non-Class P electronic type ballast inside the unit.
3. Caution — Risk of shock — Use for dry location only.
4. Not for use with light dimmers.
5. Not for use in totally enclosed fixture.
6. Has been evaluated for use with portable lamp, ceiling fixture.