

Inside the CCD housing is a camera and 2.4GHz transmitter channel selection (1,2,3), by Dip switches on the body. You can set-up channel by Dip switches.