



Remarks: W1 is used for function code
 W2 is used for start code
 Number of W1 codes (n) for Sensor #1 is 64
 Number of W1 codes (n) for Sensor #2 is 40
 Number of W1 codes (n) for Sensor #3 is 10

