

User Manual

RC boat

Remote-controller's battery installation

- 1) Release the cover of battery box
- 2) Install 2xAA batteries into battery compartment according to the right poles
- 3) Close the cover of the battery box

Car battery installation

- 1) Unlock the battery cover of the battery compartment which is back of the boat
- 2) Install 3xAA batteries into battery compartment according to the right poles;
- 3) Close the cover of the battery compartment;
- 4) Lock the battery cover.

Use instruction

- 1) Turn the power switch of boat to "ON" position;
- 2) When the user control the control stick, the LED light will be turn on; When the light is turning dimmer, the batteries are to be replaced;
- 3) Operate the handle of the controller, the boat can move Forward and Backward clockwise.
After play, turn the power switches of car-body to "OFF" position.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Legal Company Name: Innovage LLC

Address: 19511 Pauling, Foothill Ranch CA , USA 92610

Phone: 949-587-9207