

Product: DrumBass™ III BT Bluetooth Speaker

Model: FG-8011-SIL-I

User Guide

Thank you for purchasing a Lifetrons® DrumBass™ III BT Bluetooth Speaker. This pocket-sized speaker features revolutionary portable audio technology with built-in bass support and Bluetooth for wireless music. The DrumBass™ III BT Bluetooth Speaker is also equipped with a high-fidelity speaker to ensure smooth delivery of mid and high tones. It comes with a built-in rechargeable battery for easy use.

This guide outlines the operating procedures and safety precautions. Please read it carefully to make sure you are using your product properly and retain it for future reference.

What's Included

- DrumBass™ III BT Bluetooth Speaker
- 1 x Audio cable
- 1 x Micro-USB charging cable
- Storage pouch
- User guide

Compatibility

- Any portable audio device with Bluetooth connectivity feature.
- Any device with a 3.5mm input for audio playback.
- Any USB port for charging.

Please note: The USB port only supports the charging function; it is not able to function as a USB audio speaker.

Features

- Swiss-designed with an Elegant Aluminum Alloy finish.
- Built-in Bluetooth technology wireless allows transmission up to 8m.
- 10 hours of audio playback time.
- DrumBass™ Technology reveals a stunningly powerful bass.
- Advanced technology provides an excellent playback of the mid and high range tones.
- Dual Color LED indicates charging or playback status.
- Protective Grille Designed to optimize sound quality while protecting the interior of the speaker.

- Compatible with most mobile devices, such as: iPad, iPhone, iPod, PC/ Mac and other mobile device using either Bluetooth wireless or audio cable.

Specifications

- Wireless Range: 8m
- Output: 3W
- Charging time: 3 hours
- Music playing time: 10 hours
- Dimensions: Ø
- Weight:
- Rechargeable via standard USB output

How to Use

A. How to Recharge

1. Connect part ① (micro-USB jack) to ② (micro-USB port).
2. Connect ④ (USB plug) to USB port with a power supply (i.e. computer USB port or AC adapter with USB power supply).

B. How to Connect to Music Player using audio cable

1. Connect part ③ (3.5mm audio jack) directly to any music player with a 3.5mm audio jack or mobile phone via the audio connector(not included).
2. Connect the other end of audio cable to part ⑤ (3.5mm audio input) of the speaker.
3. Turn the power switch to  underneath the speaker to experience the stunning sound.

C. How to Connect to Music Player using Bluetooth

1. Turn on the power of the connecting device (music player/ computer) you want to pair the speaker with.
2. Turn on the Bluetooth function on the connecting device.
3. Turn the power switch to  underneath the speaker, it will start searching for connecting device and the LED indicator will start flashing in blue quickly.
4. Once the speakers and the device are paired the connecting device will show a prompt you to select the paired component. Select the speaker--usually the speaker will show up on the prompt as the model number (for example "FG-8011").
5. If asked for an input passkey, input the number "0000" (This is the default passkey for the majority of Bluetooth devices).

6. Once pairing is complete there will be prompt tone and the LED indicator on the speaker will keep flashing slowly.

Attention: Some of the portable devices may contain the Mini-USB/Micro-USB port. Please note that some of the Mini-USB/Micro-USB ports may only support data transfer function. If your devices (Camera, mobile phones or others) contain a Mini-USB/Micro-USB port, please read the user guide of your portable device carefully and make sure it supports charging functions.

LED Battery Indicator

When Charging:

Red flickering light – Charging

Blue light on – Fully charged

When in Use:

Blue light on – On

Red light on – Low battery

FAQ's

1. Why isn't there any sound even though the speaker is turned on?

Please make sure that the battery has been charged for at least 3 hours. The red LED will be flashing when charging. For optimal performance, please set the volume level of your MP3 to 60-70%.

2. Why isn't there any sound when I connect the speaker to my music player?

Case 1: While you are connecting the speaker with the 3.5mm audio cable, make sure your speaker switched to  function and that music is playing on your music player. Check if the volume is adjusted too low. See if the 3.5mm audio jack is properly connected. Keep in mind that the speaker is not a USB audio device; it does not play music via USB connection. USB plug is for charging only.

Case 2: While you are connecting the speaker with Bluetooth wireless, make sure your

music player turned on the Bluetooth and speaker is switch to  function and that music is playing on your music player. Check if the volume is adjusted too low. Check if the speaker and your device are paired properly, once pairing is complete there will be prompt tone and the LED indicator on the speaker will keep flashing slowly.

3. Is this a USB audio device?

No, this is not a USB audio device. The USB plug is for charging purposes only. To play music, connect the 3.5mm audio jack to any music player.

4. How can I tell if the speaker has been fully charged?

When the indicator LED changes from flashing red to solid blue, the speaker has been fully charged.

Safety Precautions

Please follow the rules outlined in this guide closely to ensure your safety and flawless operation:

- Be cautious of any edges, uneven surfaces, metal parts, accessories or packaging to prevent possible injury or damage. Take note that this product should not be placed in your mouth.
- Do not modify, repair or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. and will void the warranty.
- Do not use any kind of liquid to clean the product. Keep in mind that the surface of the product should only be wiped with a clean dry cloth.
- Do not use this product in locations with high temperatures or high humidity levels (i.e.: bathrooms); ideally, the product should be used in a location free of excessive dust and not exposed to direct sunlight.
- Do not insert foreign objects or liquids into the product; this could damage the product.
- Do not touch this product when your hands are wet; this could result in electric shock.
- Refrain from dropping the product or bumping it against other objects.
- Do not use this product in hazardous locations.
- Should any abnormal situations or problems occur while using this product, discontinue its use immediately.
- The product may explode if disposed of in a fire.

Battery

Although fully charged and ready for use, it is recommended that you completely use the initial charge up, then recharge the product at least two more times to ensure the best possible performance.

Children

Keep out of reach of children. Do not allow children to play with your product or its accessories. They could hurt themselves or others and could accidentally damage the product. Your product and its accessories may contain small parts that could become detached and create a choking hazard.

Disposal of Electrical and Electronic Equipment

This symbol indicates that all electrical and electronic equipment included with this product should not be treated as household waste. Instead, it should be left at the appropriate collection point for the recycling of electronic equipment. By ensuring this product is disposed of correctly, you are helping to prevent negative consequences for the environment and human health. To recycle this product, please contact your local city office, household waste disposal service or where you purchased the product.

Limited Warranty

If within 12 months of purchase this product or any part thereof is proven to be defective by reason of faulty workmanship or defect in materials, we will repair or replace the same product free of charge of labor or materials on condition that:

1. The original invoice or sales receipt with the date of purchase is presented with the defective unit.
2. Lifetrans does not take any responsibility for lost information of any kind and will not reimburse you for any such loss.
3. The limited warranty is only valid if the original proof of purchase for this product, issued by a Lifetrans authorized dealer, specifying the date of purchase, is presented with the product to be repaired or replaced. Lifetrans reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the product from the dealer.
4. A rechargeable battery can be charged and discharged over one hundred times. However, it will eventually wear out - this is not a defect and corresponds to normal wear and tear. When the playback-time or standby time is noticeably shorter, it is time to replace your battery. Please do not make repairs, modifications, or installations without contacting an authorized Lifetrans representative.
5. The warranty does not cover product failures which have been caused by use of accessories or other peripheral devices which are not Lifetrans branded original accessories intended for use with the product. The warranty does not cover any damage caused by misuse, abuse, neglect or accidental breakage.
6. The warranty does not cover product failures caused by modifications, repairs or disassembly by any person not authorized by the manufacturer.
7. Any defective unit or part shall become property of the manufacturer.

Additional Information

Please register your Lifetrans product online at www.lifetrans.com.

Please visit our website www.lifetrans.com or contact our customer service center at cs@lifetrans.com to learn more about our new products and special offers.

©Copyright 2012 by Lifetrans Switzerland GmbH. Lifetrans® is a registered trademark of Lifetrans Switzerland GmbH or Lifetrans International Limited. All brands and product names listed are trademarks or registered trademarks of their respective holders and are hereby recognized as such. Specifications are subject to be changed without prior notice. All rights reserved.

This user guide was originally composed in English and was subsequently translated into other languages. The fidelity of subsequent translations cannot be guaranteed. In case of conflict between the English version and another language version, the English version takes precedence.

FCC Warning:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - -- Reorient or relocate the receiving antenna.
 - -- Increase the separation between the equipment and receiver.
 - -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -- Consult the dealer or an experienced radio/TV technician for help.

FCC RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.