Do not try to disassemble the unit. . To charge KURIO, only use the power adapter supplied with your tablet

 Keep the unit out of direct sunlight and away from any direct heat source.

 Do not expose the unit to moisture or water.

If a small part is coming out of the KURIO, don't try to remove it. Keep it away from small children. · Never force a connector into a port of KURIO. If a connector and a port do not join with reasonable

force, make sure that the connector matches the port and that you have positioned the connector • To clean up the screen, simply use a soft damp cloth. Do not use alcohol, solvent, aerosol spray or

abrasive cleaners to clean your KURID.

The silicone bumper is designed to protect from light use and drops, but is not guaranteed to protect this delicate piece of electronics from severe drops, abuse, misuse, etc.

The product and micro USB cable should be periodically examined to check that they are in good condition. In case of defect, the micro USB cable should not be repaired but replaced.

MicroSD card: You can also share data using a microSD card sold separately. To insert a microSD card, pull the cover of the microSD card from the bottom side of your tablet. Make sure to move the

files to and from the appropriate folders so that they can appear properly on your tablet. We recommend that you transfer your photos and videos regularly.

In case of data transfer from your Tablet to PC or MAC, to avoid data corruption or lost data, follow the instructions in this manual. The user is responsible for any damage or loss of data, the misuse,

If for any reason, the screen (display) is cracked or broken, immediately stop using the product.
Do not drop the product or subject it to severe impact.
Do not use and do not expose the device in extreme temperatures (hot or cold), dusty conditions or

damp conditions. Do not expose the device in extreme temperatures (into total), dusty conditions or damp conditions. Do not expose to direct sunlight. Do not expose the device to water, liquids, rain, dust or moisture. If your tablet is exposed to liquid, power off the device immediately and clean/dry it.

Avoid using the device near strong magnetic fields. If your tablet has been exposed to magnetic fields, please restart the device, following the instructions in this manual, if necessary.

Please keep the box and this manual for further reference. This manual may not reflect your actual

device's operation. All information is subject to change without prior modification. Please follow your

FCC statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Represent or resocate the receiving amenia.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.
 The device must not be co-located or operating in conjunction with any other antenna or transmitter.

RF exposure information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the poser required to each the nebusy. In general, the claser way are to a wireless pass station appears the the poser required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.

Tech Support & Warranty Information

If you have any questions setting up or using your tablet, please visit www.kurioworld.com to find out more about KURIO tablet, read our FAQs, and for any technical support. All of our products have a 2 years Limited Warranty. In the unlikely event you experience any problems with your KURIO please visit www.kurioworld.com to contact KURIO Customer Care, You may also contact Customer Care through the Customer Care/KURIO Support applications on the device. If the service representative is unable to solve the issue, he or she will provide instructions regarding how to have your KURIO serviced if it is under warranty.

Please note that this tablet is warranted only to the original purchaser for a period of twenty-four months from the original purchase date, under normal use and service, against defective workmanship and materials. If the product is damaged due to accident, improper or unreasonable use or maintenance, such as broken screen, fall, water damage, etc., this damage is not covered by the warranty. Please still contact KURIO Customer Service for repair and replacement options, especially for a broken screen or other spare parts.

Restricted Use of Electronic Devices

The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with your airline company before traveling. KURIO has an Airplane Mode. Please go into the Settings of the Android Interface to switch the tablet into Airplane

especially for a broken screen or other spare parts.

Please visit www.kurioworld.com for the full details of KURIO's 2 years limited warranty.

IC statement

This device complies with RSS247 of Industry Canada. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Radiation Exposure Statement: The product comply with the Canada portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available. This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Canada RSS-102. The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the RSS-102 is 0.08 W/kg, Tests for SAR are conducted using standard operating positions accepted by the [C with the device transmitting at its highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the poser required to reach the network. In general, the operate at multiple power levels so as to use only the poser required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.

Recycling

Waste electrical products and batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice. CAUTION - ELECTRICALLY OPERATED PRODUCT -As with all electric products, precautions should be observed during handling and use to prevent electric Adult supervision is recommended. Please retain this manual for further reference.

Privacy Policy

We need you to provide us with your email address when activating your KURIO tablet and keep your email address up to date via the Parental Area to be informed of important updates and information. Your email address will never be shared with any third parties and you can unsubscribe at any time by clicking on the link provided at the bottom of every KURIO email. To read our Privacy Policy at any time, please go to www.kurioworld.com.



CAUTION: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE. DO NOT PLACE ANY OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, ON THIS APPARATUS.

© 2021 KURIO® and KD Interactive are registered trademarks of CIDE INTERACTIVE SLU. Android, Google Play, YouTube and other marks are trademarks of Google LLC; The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. TM & © 2015 Shortcake IP Holdings LLC or TM & © 2015 STRB © 2016 Orbital Nine © Zerokcm © Webcore Games 2017 Copyright © 2015 GivingTales Kft. All rights reserved. © Future Today Inc. © 2016 Kidjoi, INC KIDO'Z Ltd. - Empowering kids' digital life © 2012, All rights reserved. © 2014 Monkimun © 2016 TapTapTales © Animoca Bands © Minictlip Games © PMQ software 2013–2016 © 2019 Fruit Punch, Inc. © 2016 Witty Wings Copyryight © 2016 Toon Goggles, Inc Copyright © 2015, Twinlife. All Rights Reserved Copyright © 2017 KD PRODUCTIONS™, LIL KURIO™, the KDI™ logo, the names, the graphics, the musics and brands mentioned on this product are registered trademarks of KD GROUP™. © Perential Pictures Film Corp. All Rights Reserved. © 2019 Zulleon Ltd. © KD Productions Toons and Games © Pinpin Team "The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by CIDE Interactive is under license. Other trademarks and trade names are those of of such marks by CIDE Interactive is under license. Other trademarks and trade names are those of their respective owners. 'CronLab® is a CronLab Limited registered trademark MicroSDHC Logo is a trademark of SD-3C, LLC.

The content and colors of this package may vary slightly from the photographs.

Warning! Permanent hearing loss may occur if earphones or headphones are used at Warning! Permanent hearing loss may occu high volume for prolonged periods of time.

For more information about KURIO, please go to www.kurioworld.com or contact:

KIDS DELIGHT, LTD. GROUP IL60515

Printed in China ©2021 CIDE Interactive SLU CJB1Y10ALAAA

C21100US_KDUS_AW_UM_01_004_210225

b/ Your are looking at the tablet in a bad

position, while lying down on your back. The ollowing picture will then appear and block

any further use of the tablet. To keep using

Kurio TAB Ultra **SETUP GUIDE** FOLDABLE BUILT IN STAND

MicroUSB/CHARGER (3) Headphones 3.5mm JACK (3) Proximity Sensor

MicroSD Card slot

IMPORTANT INFORMATION PLEASE READ BEFORE SETTING UP YOUR KURIO The tablet must be set up by an adult to ensure an appropriate level of protection for all users of

- To turn off your Kurio® tablet correctly, press the power button until the pop up message appears on screen, and then select "Power off". Avoid switching off the device by pressing and holding the
- power button until the unit stops. Password reset: Tech support may not be able to retrieve your parental area password, so please don't forget to note it in a safe place. In case of a lost password, the tablet may have to be factory
- reset and all personal data will be lost. Updates are pushed to your tablet wirelessly.
- If you encounter any issue with your device, please do not return it to the store. Please review our FAQs & troubleshooting info or contact our tech support team for help at
- Please note that part of the memory is used for internal system and for pre-installed applications.

Find more tips and information on www.kurioworld.com

Installation & Update Before using your Kurio® Tablet for the first time:

2. Charge the tablet for 3 hours, using the supplied adaptor
3. Press the power button for 5 seconds to turn the tablet on

KURIO setup

- Setup all the following elements to make your • Parent setup: Enter an email address and
- check the Terms and Conditions. Password: To protect your parental account. you must set up a password.








KURIO child mode interface

- Favorites: To add apps into the Favorites section, keep your finger pressed on the selected app, and drag and drop it to the "Add to favorites" icon that appears on the top of the screen.
- Kurio Selection: Access our pre-selected apps. • Lil' Kurios®: Access all entertaining Lil Kurios® nursery rhymes videos Active: Access all apps to keep you fit and active.
- Education: Access all educational and STEM apps. · Creative: Access all creative apps.
- Games: Access all games. • Apps: Access all authorized apps.





Lil' Kurios® Videos

Kurio Selection

KURIO GENIUS Overview

Touch the SETTINGS icon 🙆 to access the Kurio Genius parental control dashboard.

Main menu On the main screen, touch each title to enter the

corresponding section and set the parameters. • Child profile's information: You can modify

- your child profile's name, birthday and gender at the top of the screen. Application Management: To allow or block each application installed on the tablet.
- Google Assistant is ON by default. You can turn it off at any time. Time Control: To configure hours of use per day and play time.
- Web Access: To allow, block or manage Internet access, use web filtering or web list.
 Blue Light filter: is OFF by default. Switch it on to filter the amount of blue light displayed on
- the screen and reduce the digital eyestrain, so eyes won't feel so tired by the end of the day.

 Ear protection: This mode is intended to avoid the volume being increased to a level that
- could cause harm to a child's hearing when using a headphone.
 Proximity sensor / posture coach: sensors are ON by default. You can switch them OFF at

Games When ON, the sensors of the tablet will detect if: a/ You are too close to the tablet's screen - All APPS The following picture will then appear and block any further use of the tablet. To keep using your tablet, move it away from your

Education

off by default. Every new app your child downloads from Playstore and Kidoz Store needs to be approved first in the App

Management section (in Kurio Genius) before he can see it in his profile and play with it. Turn this option on if you want each app your child downloads to be automatically accessible without your prior review / authorization.

Google Assistant: Turn off the Google Assistant if you do not want your child to use it. Time Control

Thanks to the Time Control menu, you can setup different time parameters to control your child's use of his apps. You may limit he access to his apps at specific times of the day and for a specific duration.

Application Management

Authorize new apps auto: This option is turn

Display suggested app: This option is ON by

Choose the time slot by dragging the cursors to define the hours within which the child will



31

💪 🖳 🖳 🙆 M

You can do this for the whole week but also set different settings for specific days using the tabs at the top of the screen.

default. It would display a list of curated apps in the child's profile. Turning OFF would remove all

suggested apps that are not downloaded and installed from the Child's profile.

Web Access

Our advanced filtering system allows children to access thousands of websites safely, by blocking websites that may contain inappropriate content.

Turn off web access from the KURIO GENIUS main menu to block all access to the web. Turn on the web filtering to use predefined filters of websites according to the age of your child. (Press the web access title to access more ontions.) Turn on the web list to use your personalized list of websites. (Press the web access title to access more options).

Web Access menu:

Web filtering: Use the automatic web filtering list adjusted to your child's age by default or turn on custom parameters on the bottom right hand corner of the screen to disable or activate the filter on specific categories of your choice. You can press "Set to current age" at any time to

Web list: Create and manage a list of websites tick shows the web site is authorized while the red cross means the web site is blocked.



Using the micro SD card

The Micro SD card can be used in 2 ways:

Portable storage: micro SD card is used for files transfer such as videos, music and photos from one
device to another. You may remove the card from the tablet if needed.
 Internal storage: if you choose this option, your micro SD card will become an internal storage for
the tablet. So you can install apps to it and save app data to it.

Caution: If you use micro SD card as internal storage, the Android system will format it in a way it won't Laution: If you use micro SD card as internal storage, the Android system will format it in a way it won be recognized by other devices. The micro SD card shall not be removed from the device. In case you removed the SD card, the device may not work properly. To fix it, please insert the existing micro SD card. When choosing the option "use as internal storage", the system will ask you if you want to move data to new storage. Please choose "move later". For more details about using the micro SD card as internal storage, please check our FAQ on the website.

Tips and Recommendations

While using some applications that use a lot of the device's processing capacity, the device may become warm. If this occurs, take a short break from using the device to let it cool down.

Keep the unit clean by wiping it with a slightly damp cloth.

The Kurio® bumper protects your tablet in most cases, but is only intended to make the product more resistant to damage due to falls, bumps or other impact damages. Like any other electronic device, Kurio® is fragile and despite the presence of the protective bumper, can break or be damaged from forces like dropping, banging, or being hit by other things. Please handle with care. Broken screens and touch panels are not covered by the warranty, and no bumper can prevent all damage.

Do not damage or deform the power supply USB cord. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cord.

The power adapter & cord should be plugged in near the unit, so it is easily accessible and does not strain the cord.