



**WorldCast**  
Systems  
deliver > transmit > monitor

apt | deliver

ecreso | transmit

audemat | monitor

# Block Diagram

## HELIOS 350W

### O35-HFM0350W



**Block Diagram**

