


External Photographs


All View



EUT View



EUT View



EUT I/O Port




EUT I/O Port




EUT I/O Port



Adapter



Adapter




Adapter Input



Adapter Ferrier Core




Adapter Output



Adapter Label



Wi-Fi and BT Antenna



Wi-Fi and BT Antenna

