



**Pegasus Active Triple
Field Antenna**

Pegasus Control Box






Antenna Connected to Control Box

Below: Control box showing:

1. Antenna connection (left)
2. RS232-C interface connection (middle)
3. Mains input (right)





Antenna Connector - 7 Pin Circular, Weatherproof Connector.