



Annex G. Photographs

G.1 Test Sample


Front Sample 211228-02.S01 	Back Sample 211228-02.S01 
Convertible 211228-02.S01 	Convertible 211228-02.S01 
Laptop 211228-02.S01 	

Front Sample 211228-02.S02 	Back Sample 211228-02.S02 
Convertible 211228-02.S02 	Convertible 211228-02.S02 
Laptop 211228-02.S02 	

G.2 PD Test positions

Laptop @2.5mm	Laptop @2.5mm
	

G.3 SAR Test position

Back Face	Bottom Edge
	
Laptop	
	

G.4 Antenna host platform location and adjacent edge positions relative to the body

All information (diagrams, values and dimensions) in this section is provided by the manufacturer

Antenna Host Platform location




Diagram illustrating the top-down layout of the laptop chassis with antenna locations (A, B, C, D, E, F, G, H, I, J, K) and their distances from various edges (Top, Bottom, Left, Right). The diagram shows the positions of the Main and Aux antennas relative to the chassis edges.

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
A	WLAN-Aux	to Top	204.88
B	WLAN-Aux	to Right	221.71
C	WLAN-Aux	to Left	68.59
D	WLAN-Aux	to Bottom	5.0
E	WLAN-Aux	Aux Antenna Length	30
F	Main-Aux	Main to Aux	114.16
G	WLAN-Main	to Top	204.88
H	WLAN-Main	to Right	62.55
I	WLAN-Main	to Left	212.75
J	WLAN-Main	to Bottom	5.0
K	WLAN-Main	Main Antenna Length	45

Antenna Host Platform location




Diagram illustrating the front view of the laptop chassis with antenna locations (Q, R, P, S) and their distances from various edges (Front, Rear, Left, Right). The diagram shows the positions of the Main and Aux antennas relative to the chassis edges.

Minimum Separation Distance			
Item	Antenna	Position	Distance (mm)
Q	WLAN-Aux	to Front	1.5
P	WLAN-Aux	to Rear	13.8
R	WLAN-Main	to Front	1.5
S	WLAN-Main	to Rear	13.8

Laptop Mode




Diagram illustrating the side view of the laptop in Laptop Mode. The Main antenna is located 15.65 mm (w/o Bumper) from the bottom of the laptop. The diagram shows the position of the Main antenna relative to the bottom of the laptop.






Diagram illustrating the top-down layout of the laptop chassis in Laptop Mode. The Main and Aux antennas are located 15.65 mm from the bottom of the laptop. The diagram shows the positions of the Main and Aux antennas relative to the bottom of the laptop.

G.5 Phantom liquid level during measurements

ELI phantom Head liquid SAR SPEAG HBBL600-10000V6 Batch - 191016-2



ELI phantom Head liquid SAR SPEAG HBBL600-10000V6 Batch - 210331-01



End of the report

This page is intentionally left blank and marks the last page of the test report.