


# 941Y Board Diagram



(i) The frequency is the frequency that the antenna received

(ii) The L.O. is 433.12MHz

(iii) The frequency is the clock of the MCU for normal operation

## Block Diagram of RF3310A

