

# Grand ultimate wireless

FCC ID : PVCP135

GRANDTEC ELECTRONIC CORP.

The information in this document is subject to change without notice and does not represent a commitment on the part of the developer.

This document contains materials protected by copyright. All rights are reserved. No part of this manual may be reproduced or transmitted in any form, by any means or for purpose without express written consent.

## **FCC DECLARATION**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **Federal Communications Radio Frequency Interference Statement.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off or on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice :

- (1) The changes or modifications not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

Shielded VGA cable must be used in order to comply with the emission limits.

Printed in Taiwan R.O.C.

All contents are subject to change without notice.

All trademarks are the property of their respective owner.

## CONTENTS

<b><u>CHAPTER 1 WELCOME TO GRAND ULTIMATE WIRELESS.....</u></b>	<b>1</b>
1.1 INTRODUCTION.....	1
1.2 FEATURES.....	1
1.3 MODE AND RESOLUTION TABLE.....	2
1.4 SYSTEM REQUIREMENT.....	3
1.5 PACKAGE CONTENTS .....	3
 <b><u>CHAPTER 2 INSTALL GRAND ULTIMATE WIRELESS .....</u></b>	 <b>5</b>
2.1 CONNECTORS OF GRAND ULTIMATE WIRELESS.....	6
2.2 BUTTONS & SWITCH OF GRAND ULTIMATE WIRELESS.....	6
2.3 CHANNEL SETTING.....	7
2.4 INSTALLATION FOR IBM PC USER.....	7
2.5 STEP BY STEP CONNECTS.....	9
 <b><u>CHAPTER 3 TECHNICAL TIPS .....</u></b>	 <b>12</b>
 <b><u>CHAPTER 4 TROUBLE SHOOTING .....</u></b>	 <b>13</b>

ISSUE: 2001/07

VERSION: A

P/N: 3413500