Be sure to read this manual before use

XPERIA XX XX XXXXX

Cautions on using the product

- In this manual, "Xperia XX XX" is usually referred to as "the product" or "main
- In this manual. "Quick Start Guide". "Cautions on using the product" (this manual) and "取扱説明書 詳細版 (Full instruction manual)" (Japanese) are
- manual and waxaxaysia +aunx (uninsuculor manual) (depanes collectively referred to as "instruction Manual".

 Descriptions in this manual are based on Android™ 12.

 In this manual, "microSD™ memory card (commercially available)".
- microSDHC™ memory card (commercially available)" and "microSDXC™ memory card (commercially available)" are abbreviated as "microSD
- Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM and ® marks may be omitted in this manual.
- Follow the instructions of a gas station or other such location

before using the product there. Do not charge the product at a gas station, etc Take care not to drop the product at a gas station, etc.; in particular, not use the product while filling. Ignition of flammable gas might cause explosion, fire, etc.

If you notice anything unusual about the equipment such as an unusual odor, abnormal noise, smoke generation, overheating, discoloration or deformation during operation, charging or storage, perform the following measures carefully.

e the power plug from an outlet Turn off the power of the product Failure to do so might cause fire, burns, injury, electric shock, etc.

Caution Be sure to read the following cautions before use

Do not use damaged product or peripheral devices.

Doing so might cause fire, burns, injury, etc

Do not place the product on an unstable or inclined platform. Be careful especially when vibrator is set.

The product might half and Gaussian, and Do not use or keep in a place that is very humid, dusty, or subject

ng so might cause fire, burns, electric shock, etc. pofness, refer to "Notes on waterproof and

dustproof properties" (▶P.26).

If children use the product, parents or guardians should give them proper instructions and do not allow them to use the product in the wrong way. Use of the product in the wrong way might cause accidental

ingestion, injury, electric shock, etc

Never connect the USB Type-C plug to the product or the

fire damage, fire, burns, or a fault if corrosion occurs.

Doing so might cause fire, burns, electric shock, etc

specified charging equipment (sold separately) when it is wet.

Type-C plug to the product when it is wet might cause electric shock

Do not touch the cable, charging terminals or power plug of the specified charging equipment (sold separately) with wet hands.

Use the adapter only on the specified power supply and voltage. When charging the battery overseas, use AC adapter that can be

Using the incorrect power supply and voltage might cause fire, burns.

AC adapter (sold separately): 100V AC (Connect to the AC outlet for

240V AC (Connect to the AC outlet for internal household use)

AC adapter (sold separately) that can be used overseas: 100V AC to

rcuit due to the moisture or foreign substance on the

oduct or USB Type-C plug, or might cause abnormal overheating,

uct has the waterproof property, inserting USE

When using the product

Before you start using the product, make sure to read the "Safety Precautions

Before you assume that the product is malfunctioning, refer to "故障とお考え になる前に (Check here first)" in "取扱説明書 詳細版 (Full Instruction Manual) Communication is not possible even inside of the service area in places

- where the signal does not reach (e.g. tunnels and basements). Also, communication is sometimes not possible in poor signal reception areas. Communication is sometimes interrupted if you move into poor signal reception area during communication.

 Since the product uses radio waves, the possibility of co
- ntercepts by third parties cannot be eliminated. (Though 5G/LTE/WiMAX 2+, GSM/UMTS system has highly secure confidential communication features.)
- For connecting to the emergency call acceptance organization, VoLTE (LTE network) is used. 3G (Line exchange network) connection is not available.

 Since the product is a radio station under the Radio Law, you may be asked to
- emporarily submit the product for inspection in accordance with the Radio Law. The IMFI information of your mobile phone is automatically sent to your
- Before you start using the product overseas, check the relevant laws and regulations of the country/region you visit.
- The Company is not liable for any damages arising from earthquakes, lightning, storms, floods or other natural disasters, as well as fires, actions by third parties, other accidents, intentional, mistaken, or incorrect use by the customer, or use under other unusual conditions outside the esponsibility of the Company.
- The Company is not liable for any incidental damages (change/ disappearance of described content, loss of business income, disruption of business, etc.) arising from use of the product or inability to use the product.
- The Company is not liable for any damages arising from failure to observe the described content of the "Instruction Manual"
- The described content of the instruction waithful You cannot use information obtained from the measuring sensor or GPS equipped with the product for the purpose which requires high reliability. Note that the Company is not liable for any damage or lost income arising from the difference caused by measurement.
- The Company is not liable for any damages arising, for example, from malfunction caused by combination with connected devices or software not related to the Company. 0

Keep the equipment out of the reach of babies, infants, and pets.

In particular, be careful where small parts are stored, such as the

nicroSD memory card/SIM card tray ailure to do so might cause accidental ingestion, injury, electric

Be careful about the temperature when using the product continuously or while charging because it might become warm. Also, be careful not to keep touching it unintentionally in a pocket

The product or the specified charging equipment (sold separately) might become warm when using an app, a call, data communication, watching video, playing a game, etc. continuously or while charging. If you are directly in contact with warmed part continuously, it might cause a redness of skin, itch, rash, low-temperature burn, etc. depending on your physical condition. Especially, be careful when you put the product in a pocket of clothes or at bedtime

Main unit

Danger Be sure to read the following hazards before use.

Do not throw the product into fire or apply heat. Doing so might cause fire, burns, injury, etc.

If the internal substance of the product contacts your eyes or ne internal substance of the product contacts your eyes or uth, immediately rinse the eyes or mouth with clean water and

hen see a doctor right away. ne effects of the internal substance of the product might cause

olindness, medical problem, etc.

Do not put excessive force such as sticking with a sharp object (nail etc.), hitting with a hard object (hammer etc.), or stepping on it.

Doing so might cause fire, burns, injury, etc.

If the charging terminal is deformed such as being bent, stop using immediately. Do not use it with the deformation restored. Doing so might cause fire, burns, injury, etc. due to short-circuit of the

Always remove the power plug from an outlet when not using it. Keeping it plugged in might cause fire, burns, electric shock, etc.

Immediately remove the power plug from an outlet if liquids such

ure to do so might cause fire, burns, electric shock, etc. due to short-circuit by adhered object etc.

Before cleaning, remove the power plug from an outlet.

Caution Be sure to read the following cautions before use.

Do not touch the specified charging equipment (sold separately) continuously when it is connected to an outlet. Doing so might cause a burn etc




Caution

Be sure to read the following cautions before use.

Be careful of the cut surface not to hurt your fingers etc. when nandling SIM card.

The cut surface may be sharp, and it might cause injury.



damages or lost profits resulting from altered or lost contents.

Note that contents data (both charged or free content) saved to the product cannot be returned to the customer when the product is replaced for repair of a fault, for example.

due to faults, repair or other handling of the product. The Company is not liable for any damage or lost income resulting from recovery of these data.

mended you keep a copy of important data on your PC's hard

 Although an afterimage may occur when a same screen has been displayed for a long time, it is not a malfunction. You are recommended to set the sleep time to a short one to avoid occurrence of afterimage and save the battery Although the display used for the product is made using high-precision

technology, some pixels (dots) might be lit or out at all times. This is not a malfunction.

• You are recommended to store copies of individual data such as photos you took, videos and music on your PC by sending each file as mail attachment etc. Note, however, that you may not be able to make copies of any

copyrighted data even by the above-mentioned means.

On not discard the product together with regular trash. Please cooperate in the collection of the product (including optional accessories) when it is no longer needed to protect the environment and effectively use resources he Company" as appears in the manual refers to your carrier and the anufacturer (Sony Corporation).

Reproduction of the content of "Instruction Manual" in part or in whole is prohibited.

Warning Be sure to read the following warnings before use.

Doing so might cause blurred vision etc. Also an accident such as

Do not look at a repeatedly-blinking screen for a long time.

Do not set a microSD memory card or SIM card in wrong

Doing so might cause fire, burns, injury, electric shock, etc.

Do not allow liquids such as water (drinking water, sweat, seawater

rine of pet animals, etc.), metal parts, or flammable objects to nter to the microSD memory card/SIM card slot of the product.

Do not expose the camera lens to direct sunlight for a long time.

Power off the product or put it in Airplane mode before boarding

Doing so might cause fire, burns, injury, etc. due to light-collecting

Use of mobile phones on board is restricted. Follow the instructions of

he radio waves from the product might adversely affect on-board

Prohibited acts related to mobile phone usage on an airplane might

Follow the instructions of each medical facility for the use of

Power off the product in a place where the use is prohibited.
The radio waves from the product might affect electronic equipment

■ Using near medical equipment or in healthcare facilities

Warning Be sure to read the following warnings before use.

If you wear electronic medical equipment such as an implantable

arry or use the product 15 cm or more away from the implant at

The radio waves from the product might have harmful effects on the

If you need to use electronic medical equipment other than implantable cardiac pacemakers or implantable cardioverter

consult the relevant medical electronic equipment ma

defibrillators outside medical facilities such as treating at home.

he radio waves from the product might have harmful effects on the

you cannot freely move around, set the product not to emit radio

roduct might have harmful effects on the operation of the electronic

Follow the instructions given by the respective medical facility

The radio waves from the product might have harmful effects on the operation of the electronic medical equipment.

A person in close proximity to you might wear electronic medical equipment such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator. The radio waves from the

If there is any chance that the distance between the product and a person closest to you might get shorter than 15 cm such as when

operation of the electronic medical equipment

operation of the electronic medical equipment.

medical equipment.

wave in advance (Airplane mode, power off, etc.).

regarding use of the product on their premises.

cardiac pacemaker or an implantable cardioverter defibrillator.

0

luminescence part close to the other's eyes. Keep enough distance away especially from bables.

Do not turn on or flash Flash/Photo light toward a driver of a car etc.

Do not turn on or flash Flash/Photo light with the lighting

injury might occur if he or she is dazzled or frightened.

Doing so might cause cramp, loss of conscious

insertion, or insert it in wrong orientation.

electronic equipment.

8

mobile phones on their premises.

and electronic medical equipment.

The content of "Instruction Manual" is subject to change without notice. Some functions may be unavailable due to change of specification of the OS or change/termination of services. Every effort has been made in the preparation of "Instruction Manual".

Should you notice any unclear points, omissions, etc., feel free to contact

Always keep the product away from your ear when you call handsfree, while sounding the ringtone loudly, or during stand-by.

Safety Precautions (Observe Strictly)

ners using the product.

!\ Warning

! Caution

■ Before using this product, thoroughly read these safety precautions

ved to prevent damage to property or injury to the custo

■ The following symbols indicate the different levels of injury or damage

that may result if the guidelines are not observed and the product is

his symbol indicates that "death or serious injury*1 ma

his symbol indicates that "death or serious injury" m

rectly and immediately result from improper use

his symbol indicates that "minor injury"2 and/or

temperature), electric shock, broken bones, injuries with

residual aftereffects from poisoning etc., and injuries requiring hospital admission for treatment or long-term

electric shock, etc. that do not require hospital admission for

roperty damage*3 may result from improper use"

■ These "Safety Precautions" describe instructions that should be

*1 Serious injury: This refers to loss of sight, injury, burns (high- and low

hospital attendance as an outpatient.

*3 Property damage: This refers to extended damage to buildings, furniture,

*2 Minor injury: This refers to injuries, burns (high- and low-temperature),

livestock, pets, etc.

oud sound is emitted from the product when calling with hands-free se Even in standby mode, a ringtone or an alarm sound may sound

disability of ears such as deafness. Moreover, too loud sound makes you barely hear the surrounding sounds and may cause an accident.

If you have a weak heart, set the vibrator or ringtone volume

astonishes you and it may affect your heart.

the relevant medical electronic equipment manufacturer or vendor whether the operation might be affected by radio waves.

operating on high precision control or weak signals.
The radio waves from the product might interfere with the electronic devices or equipment.

defibrillator, other electronic medical equipment, and other automatically controlled devices or equipment. If you use an implantable cardiac equipment, check with the medical electronic equipment manufacturer or dor whether the operation can be affected by radio waves.

product when the display, or the camera lens is broken. Touching damaged or exposed part might cause burns, injury, electric shock, etc.

1

Main unit

Material list

Part	Material	Surface treatment
Exterior case (top part, bottom part, side part)	Nylon resin (with glass fiber)	Coating
Exterior case (Volume key/Zoom key, Back cover)	Polycarbonate resin	Coating
Exterior case (cover of microSD memory card/SIM card slot)	Polycarbonate resin (with glass fiber)	Coating
Exterior case (Camera ring (peripheral part of main camera))	Aluminum alloy	Alumite treatment
Transparent plate (Display)	Hardened glass	AFP treatment
Transparent plate (Camera lens)	Hardened glass	AFP treatment + AR treatment
Flash/Photo light part	Acrylic resin	_
Power key/Fingerprint sensor	Epoxy resin	Coating
Earpiece mesh	PET	_
Speaker mesh	Polycarbonate resin	_
Rubber seals on the cover of microSD memory card/SIM card slot	Silicon rubber	_
Tray of microSD memory card/SIM card	Polycarbonate resin (with glass fiber) + SUS plate	_

Also, when you play game, play back videos, music, etc. ophone, etc. to the product, adjust

Listening to loud sound for long hours continuously may cause a

Sudden vibration or ringtone sounding when for incoming call

If you are wearing any electronic medical equipment, check with

Power off the product near electronic devices or equipment

The following are some electronic devices or equipment that you should be careful of:

earing aids, implantable cardiac pacemaker, implantable cardioverter pacemaker, implantable cardioverter defibrillator, or other electronic medical

Be careful about broken parts or exposed internal part of the

3

the product firmly, and do not shake it unnecessarily. Failure to do so might cause an accident such as injury. If the display is damaged and when the internal substance etc. leaks out, do not allow it to contact your skin such as face and

If the internal substance gets into your eyes, mouth, etc. or contacts your skin or clothes, immediately rinse with clean water

a doctor after rinsing. Do not discard the product together with other garbage.

the fluid to contact with your skin of face, hands, clothes, etc. Doing so might cause injury etc. on your eyes or skin If the internal substance gets into your eyes, mouth, etc. or contacts

your skin or clothes, immediately rinse with clean water.

n the case of getting into your eyes, mouth, etc., immediately consult a doctor after rinsing.

18

se precautions are provided to prevent the product from damage and Thoroughly read these precautions to ensure correct use.

■ Precautions common to the main unit, internal battery. charging equipment, SIM card, peripheral devices

Handling precautions

 Do not apply excessive force to the product during use. Be sure not to put the product into a tightly packed bag or place a heavy object on the product in a bag. Sitting on the product in your pocket might damage the splay or internal circuit board or cause a malfunction Keeping an external device connected to the USB Type-C port or headset jack might cause damage of the connector or a malfunction. Such damage and malfunction are not covered by the warranty, even if there is no external damage.

To ensure waterproof property (equivalent to IPX5 and IPX8) of the product, use with the cover of microSD memory card/SIM card slot tightly closed. Note that the waterproof property is not guaranteed in every usage

Do not allow water to get inside of the product or splash water on the specified charging equipment (sold separately) or optional accessories. It not open or close the cover of microSD memory card/SIM card slot in the rain or with water droplets on the surface of the product. Doing so might cause water intrusion resulting in internal co Malfunctions determined to be caused by water intrusion are not covered by the warranty.

 Waterproof/dustproof performance might not be maintained if the produc has an outward abnormality such as damage or deformation. I make an inquiry to the contact on the back cover of "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

● For the following products, do not use them in extremely hot, cold or humid places (Use within an ambient temperature range of 5℃ to 35℃ and humidity range of 35% to 85%. However, temporary use at an ambient temperature range of 36°C to 40°C and humidity range of 86% to 90% is allowed.)

SIM card (attached to the main unit)

Explanation of graphic symbol ndicates an action that is not allowed. dicates that disas 0 not allowed. ndicates that use in a lace where the product

licates that the powe kely to get wet or allowing plug must be disconnecte om an outlet.

licates that handling with

et hands is not allowed.

licates compulsory

Precautions common to the main unit, internal battery. charging equipment, SIM card, peripheral devices

Danger Be sure to read the following hazards before use.

the product to get wet is

not allowed.

(1)

No liquids

subject to high temperature or accumulation of heat (e.g. by the fire, near a heater, under a kotatsu or bedding, in direct sunlight, in a car in the hot sun). Do not use, store or leave the equipment in a location where it is

in a car in the hot sun).

Doing so might cause fire, burns, injury, electric shock, etc.

Do not put the equipment in cooking appliances such as microwave ovens, IH cooking heaters, or high pressure containers such as pressure cookers. Do not place the equipment near such cooking appliances. Doing so might cause fire, burns, injury, electric shock, etc.

Do not splash sand, soil or mud, or do not directly place the

equipment on it. Also, do not touch the equipment with hands with sand etc. adhered. Doing so might cause fire, burns, injury, electric shock, etc. For waterproofness/dustproofness, refer to "Notes on water pofness, refer to "Notes on waterproof and

dustproof properties" (▶P.26).

If the internal battery leaks or gives off a strange smell, immedia stop using and remove it from the vicinity of open flames. e leaking liquid might ignite, catch fire, ex

Be careful not to allow a pet etc. to bite the product. Doing so might cause fire, burns, injury, etc. because of ignition, burst, heat or leaking of the internal battery.



When using the motion sensor, check the safety around you, hold

hands, clothes, etc.
Doing so might cause injury etc. on your eyes or skin.

the case of getting into your eyes, mouth, etc., immediately consult

dispose of it according to a recycling program of your local If the substance leaks out from the internal battery, do not allow

For using the product in a car, check with the automobile manufacturer or dealer for the effects by radio waves before using. pending on vehicle model, the radio waves from the product affect the vehicle's electronic equipment to malfunction. In that case If any skin abnormality develops due to the use of the product,

Do not charge the equipment when it is wet with liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.).

Also, do not charge the equipment in a place where water comes

Do not subject the product to strong pressure or break the product. Especially when bringing the product putting in a pocket of clothes, do not let the product hit against surroundings or

ng so might cause fire, burns, injury, electric shock, etc.
waterproofness, refer to "Notes on waterproof and dustproof

ing so may cause fire, burns, injury, etc. due to damage of the

· Sitting or squatting with the product put in a pocket of trousers or skir

Putting the product in a pocket of outer wear and catching them in a

Stepping on the product on a soft object such as a sofa, bed or bedding, or on a floor

Putting the product into a seat of train or bus

Do not disassemble or modify the equipment

Doing so might cause fire, burns, injury, etc

the product.
Doing so might cause fire, burns, injury, etc.

Doing so might cause fire, burns, injury, electric shock, etc.

Do not try to remove the internal battery from the product.

Do not let the equipment get wet with liquids such as water

(drinking water, sweat, seawater, urine of pet animals, etc.).
Doing so might cause fire, burns, injury, electric shock, etc.
For waterproofness, refer to "Notes on waterproof and dustproof

The back cover cannot be removed. Do not try to remove it from

following are examples that you should be careful of:

in contact such as bathroom or near a humidifier

properties" (▶P.26).

door or a door of car

properties" (▶P.26).

attached to the product.

range of 35% to 85%.)

Charging equipmen

4

being put between the objects.

nediately stop using the product, and consult a doctor. Depending on your physical constitution or health, itchiness, a rash, See "Material list" (P.17) for materials used in each part of the

Magnetic components are used in the product's earpiece (center top), speaker (bottom left on back), and vibrator (bottom right on top), speaker (bottom left on back), and vibrator (bottom right on top), and vibrator (bottom right on top), and vibrator (bottom right on top).

ched objects might cause injury, etc Do not leave the main unit in the reach of children or persons requiring supervision.

back); make sure no metal objects (cutter blade, staple, etc.) are

The product uses magnets. If swallowed, there is a risk of choking or serious harm to internal organs.

If the magnet has been swallowed, immediately consult a doctor.

Do not bring the main unit near medical devices. he product uses magnets; they may affect pacemal pressure hydrocephalus shunts, and other medical devices. Do not

bring the product near persons using these devices. If you use such a device, consult your doctor before using the product Watch the display in an adequately bright place taking a certain

Watching in a dark place or closely might reduce visual acuity etc.

 For the following products, do not use them in extremely hot, cold or humid places (Use within an ambient temperature range of 5℃ to 35℃ and hu

Do not use in places subject to lots of dust or vibration. Doing so might

Clean the USB Type-C port and headset jack with dry cotton swabs etc

exert strong force to clean the USB Type-C port and headset lack to

Forceful rubbing with a dry cloth might scratch the display. The display

might be stained if splash or smear is left attached to the surface. Wiping

the product using alcohol, thinner, benzene, detergent, glass cleaner, etc.

• Use as far away as possible from land-line phones, TVs and radios. Use of

The product might become warm while talking, charging or during other

Do not place near corrosive chemicals or in places where corrosive gas is

Do not put the product in a cooking apparatus such as microwave oven or a pressure vessel. Doing so might cause a malfunction.

Doing so might cause a malfunction. Modification of the product is in

ation of the Radio Law and Telecommunications Business Act.

Do not allow a part of your body such as finger or conductive foreign objects (metal fragments, pencil leads, etc.) to come into contact with enter the USB Type-C port or headset jack. Doing so might cause a

The customer is not allowed to disassemble, modify or repair the product

operations, depending on the situation, but this is not abnormal

 \bullet Do not use outside when you can hear thunder. Doing so might risk

Be sure to use only the specified peripheral devices. Use of other

• Clean the product with a soft dry cloth (e.g. wiping cloth for eyegle

hight erase the printing on the exterior case or cause a malfunc

he product nearby might affect them.

lightning strikes and electric shock.

generated. Doing so might cause a malfunction.

peripheral devices might cause a malfunction.

every now and then. Soiled terminals might cause poor connection. Do not

12

19

separately). Doing so might cause ignition, overheating, electric shock, etc.

Do not put an excessive force to the connection part with the specified on the connected to the product.

In the event that the product gets wet while charging, immediately disconnect the plug of the specified charging equipment (sold separately).

motorbike is prohibited by law. Use of a mobile phone while riding a bicycle night be punishable by some regulations Using or charging the product in a bag or when it is covered with bedding

external device, insert/remove the connector straight to/from the terminal. Make sure the orientation of the connector is correct. Unless it is correct, it

Do not expose the camera lens to direct sunlight for an extended period. Doing so might cause a malfunction.

 Do not use, store, and leave the product in places subject to direct sunlight (e.g. in automobiles), places that get hot, places that get extremely cold, and in humid or dusty places. Doing so might cause a malfunction.

especially while charging or when vibrator is set. The product might fall and cause a malfunction etc

uct, for example, by starburst conne

(3)

Warning Be sure to read the following warnings before use.

Do not subject the equipment to strong force, impacts, or vibration such as letting it fall, stepping on it or throwing it.

Do not allow liquids such as water (drinking water, sweat, seawater, urine of pet animals, etc.) to get inside the charging terminal, the USB Type-C® port, or the headset jack.

ness, refer to "Notes on waterproof and dustproof

properties* (▶ R.26).

Use only optional parts specified by the Company for the product.

They then specified, or those with indefinite

ing devices other than specified, or those with indefinite anufacturer, retailor, or specifications might cause fire, burns, injury,

Do not allow conductive materials (such as metal objects and 0 pencil lead) to come into contact with the charging terminal, the USB Type-C port, or the headset jack, or allow dust to get inside

Doing so might cause fire, burns, injury, electric shock, etc Do not cover or wrap the equipment with a cloth or bedding in

use or while charging. Doing so might cause fire, burns. etc

If charging does not finish after specified time, stop charging. charging does not finish after specified time, stop charging.

illure to do so might cause fire, burns, injury, etc. due to overcharge Always turn off the product before you enter a place where

flammable gas may be present, or a place where dusts are generated. Stop charging the product if you are charging it. gnition of flammable gas might cause explosion, fire, et

■ Charging equipmen

properties" (▶P.26).

electric shock, etc.

0

(3)

5

Warning

Be sure to read the following warnings before use.

Do not use the specified charging equipment (sold separately) if Doing so might cause fire, burns, electric shock, etc

If you hear thunder, do not touch the specified charging equipment (solid separately). oing so might cause electric shock etc

Do not short-circuit the charging terminal while it is connected to an outlet. Do not touch the charging terminal with your hands, fingers, or any part of your body. Doing so might cause fire, burns, electric shock, etc

Do not place heavy objects on a cable of the specified charging

continuent (sold separately), or do not apply unreasonable force to the

able such as pulling. Doing so might cause fire, burns, electric shock, etc Do not contact metal objects to the specified charging equipment (sold separately) when connecting the plug to or disconnecting it

from an outlet. Doing so might cause fire, burns, electric shock, etc

Do not connect the voltage converter (such as a travel converter for overseas travel) to the specified charging equipment (sold

Doing so might cause fire, burns, injury, electric shock, et

 Do not use the product while driving an automobile or motorized bicycle, riding a bicycle or walking. Use of a mobile phone while driving a car or

When using the specified charging equipment (sold separately) or an

Do not place the product on an unstable or inclined platform. Be careful

Do not exceed the rating of outlet or wiring device when charging the

Clean dust from the power plug.
Using it with dust adhered might cause fire, burns, electric shock, etc.

used overseas (sold separately).

Although the pro

electric shock, etc.

Firmly insert the specified charging equipment (sold separately) cure inserting might cause fire, burns, electric shock, etc When you disconnect a power plug of the specified charging

Pulling the cable of the specified charging equipment (sold separately) might damage the cable causing fire, burns, electric shock, etc. When plugging/unplugging the specified charging equipment (sold separately) into/from the product, plug/unplug it straight

equipment (sold separately) from an outlet, do not appl

toward the product without applying excessive force such as



14

t plugging/unplugging might cause fire, burns, injury, electric

excessive force to it such as pulling the cable. Instead, hold the



7

replacing the battery, contact "お問い合わせ先 (For inquiries)" on "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese). $\ensuremath{\bullet}$ Do not forcefully press, tap or intentionally subject the display to strong impact. Doing so might cause scratching or damage. While writing or reading data to or from a microSD memory card, do not subject the product to vibration or impact, or turn off the power. Doing so

 Do not forcefully press the keys or display surface with your fingernails or hard objects. Doing so might cause scratching or damage of the keys or

• Do not use a remodeled product. Use of a modified device violates the Radio Law and Telecommunications Business Act.
The product is compliant with rules on the technical standard conformance of specified wireless equipment based on the Radio Law/

Telecommunications Business Act, and as a proof of it, the "Technical Compliance Mark & can be checked with the product.

Checking procedure: In the Home screen, slide the screen up → [Settings] → [About phone] → [Certificates] ations of the internal components of the product are made, the

Do not bring magnetized cards such as cash cards, credit cards and prepaid cards closer to the product. It might cause loss of the recorded

and may cause scratch or damage.

product

Rubber seals

from the faucet or shower head.

After the product gets wet

damage or remove the rubber seals.

cause water intrusion or dust penetration.

■ Cover of microSD memory card/SIM card slot

of water or dirt with a clean dry cloth before closing the cover. If the cover of microSD memory card/SIM card slot is deterior

damaged, the waterproof/dustproof property becomes ineffective.

refer to "取扱説明書 詳細版 (Full instruction manual)" (Japanese)

If any liquid other than plain water is adhered to the

Make sure that the cover of microSD memory card/SIM card slot is firmly closed. Just a small particle (a hair etc.) between contact surfaces can

ause water intrusion or dust penetration.
 Do not open or close the cover of microSD memory card/SIM card slot with

gloved hands. Just a small particle (a hair etc.) between the contact surfaces

· For details on how to close the microSD memory card/SIM card slot cover,

f any liquid other than plain water (e.g. seawater, detergent, alcohol, juices)

is adhered to the product, immediately rinse it with plain water. You can wash the product under a mild flow (less than 6 liters per minute) of

tap water at room temperature (5°C to 35°C) at a distance of about 10 cm

If the product of shower nead.

If the product gets dirty, wash it with your hands holding the microSD memory card/SIM card slot cover so that they do not open. Do not use a brush.

After the product gets wet, drain water, and wipe with a clean dry cloth
In cold climates, water on the product might turn to frost. Using with frost

The rubber seal on the inner edges of the cover of microSD memory

might cause a malfunction. Do not leave the product without wiping off water

SIM card slot is important to maintain waterproof/dustproof property. Do not

When closing the cover of microSD memory card/SIM card slot, take care

when closing the evolet of microb friends yearly stands we care not to get the rubber seal caught. Forcibly closing the cover with the rubbe seals caught might damage them resulting in loss of waterproof/dustproof property. Just a small particle (a hair etc.) between contact surfaces can

If any liquid other than plain water (e.g. alcohol) is adhered to the rubber seals, it might cause deterioration in durability.
 Do not insert sharp objects into grooves around the cover of microSD memory card/SIM card slot. Doing so might damage or deform the product,

damage the rubber seals, etc. causing water intrusion or dust penetration

• Since a constant Internet connection is possible with the product, data

the Internet is required and data communication charge applies.

communication may be performed automatically by some apps, resulting in

eceive e-mails and configure various settings on the product, connection to

high data communication charges. Therefore, subscription to a data communication charge discount service or flat late plan is recommended.

To browse homepages, download apps, communicate using apps, send/

Notes on data communication charge

can cause water intrusion or dust penetration. Wipe off any minuscule droplets

When you put the product in your pocket or bag, take care that the display

might cause a scratch or damage. Take care with using a strap whose member is a hard material such as metal because it can touch the display

slot firmly closed. If the cover is open, dirt or water might get inside and certification of conformity with the technical standard conformance etc. becomes invalid. Do not use the product with the certification invalid, as it is a violation of the Radio Law and Telecommunications Business Act.

 Do not allow liquids, metal and other foreign objects to get inside the USB Type-C port, headset jack, microSD memory card/SIM card slot, earpiece, outhpiece/microphone, speaker, second microphone, etc. Take care not to place magnetized items such as magnetic cards, Doing so might cause a malfunction. speakers and TV sets near the product, as it might cause a malfunction Do not give strong impact on the product such as dropping, throwing, Putting a strong magnetism close to the product might cause a false

stomping. Doing so might cause a malfunction. Do not put the product directly on sand at a beach etc. Sand or other sma

particles might get inside the earpiece, mouthpiece/microphone, speaker or second microphone causing the volume to drop. If sand gets inside the product, it might cause a malfunction. To prevent possible hearing damage, do not listen at high volume

When suddenly brought into a warm place from a cold place, or when used

in a humid location or in a place where temperature suddenly changes (e.g. near the air discharge port of an air conditioner), water droplets (i.e.

Do not cover the proximity/light sensor with your finger or put a sticker on it.

Do not put a sticker, etc. on the proximity/light sensor. Doing so might cause a malfunction on the sensor and make the display always turned off

Usually use the product with the cover of microSD memory card/SIM card

Doing so might hinder the proximity/light sensor from detecting the ambient

under such conditions, the humidity might cause corrosion or a

might cause loss of data or a malfunction.

brightness and functioning correctly.

while receiving a call or during a call.

ensation) may be formed inside of the product. Note that when used

This mark is displayed when the surface temperature of the

product rises during use. When the mark is displayed, there is a risk of burns if you continue using the product while holding it in your hands. In this case, please refrain from holding it in your

29

36

43

Replacing parts ed to replace the parts for maintaining waterproof/dustproof

property once every two years regardless of whether any abnormality is present. For information on part replacement, contact *お問い合わせ先 (For nquiries)* on *取扱説明書 詳細版 (Full Instruction Manual)* (Japanese). Heat resistance

Do not sink the product into boiling hot water or do not splash with boiling hot water to the product. Also, do not use the product in saunas or do not

esistant to high temperatures. The product is not resistant to shock. Do not drop the product or subject it to shock. Also, do not poke the earpiece, mouthpiece, second microphone, USB Type-C port, or headset lack, etc. with a sharp

expose the product to fiery winds from hair dryer etc. the product is not

Precautions on charging

Setting app permission

2 [ALLOW]/[DON'T ALLOW]

Mobile Phone Etiquette

If the request screen appears, confirm the content and swant (e.g. "ALLOW"/"DON'T ALLOW").

Example: When activating "Music" app for the first time

1 In the Home screen, slide the screen up → [Music]

The optional accessories are not waterproof. Check the following before and Never charge the battery if the product is wet. Doing so might cause fire,

burns, injury, electric shock, etc.

 Check that the product is not wet. If you are charging the battery just after the product gets wet, drain water well and wipe the remaining water off with • Do not touch the specified charging equipment (sold separately) with wet

hands. Doing so might cause electric shock.
 Do not splash water over the specified charging equipment (sold separately) when using them. Do not use them near water such as in a bathroom, shower room, kitchen or washroom. Doing so might cause fire, burns, electric shock, or malfunction. Do not bring them into a bathroom etc. even if

you do not charge the product with them. Doing so might cause fire, burns

When you activate an app/function that access the functions or information of

If you do not permit, app/function may not be activated or use of function

To change the permission setting, in the Home screen, slide the screen up → [Settings] → [Apps] → [See all XX apps] → Tap an app to change the setting → [Permissions] → Tap a function or information of permission

setting to be changed → Select the option you want (e.g. "Allow"/"Don't

For some apps/functions, an explanation screen for the permission ma

appear. Several request screens may appear or the screen content may differ. Confirm each content and follow the onscreen instructions.

In "Instruction Manual", description of the confirmation screen may be

■ Use of the product is not allowed in the following places!

punishable by law). In addition, stay alert to the traffic around you even

the screen might distract your attention causing a traffic accident. Be especially careful at railroad crossings, station platform and pedestrian

Use of mobile phones on board is restricted. Follow the instructions of each

when walking. Surrounding sounds may not be heard clearly, and gazing at

en appears, confirm the content and select the option you

the product for the first time, a confirmation screen for requesting access

Draining water when the product gets wet

enough not to drop it.

Consider people around you

shinkansen, a hotel lobby etc.

• Be careful not to be loud while talking.

instructions of that medical institution.

performance and to get the latest enhancements.

■ Downloading and updating software

communication charges may be incurred.

Updating Software

mmunication. A large amount opecially for upgrading the OS.

and not a malfunction. Please be forewarned.

■ Display (Touch Panel)

cause malfunction.

the touch panel.

■ Organic EL display

Operation with gloves

Operation with wet or sweaty fingers

Operation under water

false operation of the touch panel.

The touch panel is designed to be lightly touched by fingers. Do not apply

strong pressure with your fingers or sharp-pointed objects (such as fingermails, ballpoint pens and pins) to the touch panel.

In the following cases, the touch panel might not respond. Also, it may

Operation with fingernails
Operation with foreign object on the touch panel
Operation with protective sheet or seal on the touch pan

· Operates when the display is wet with water droplet or fogged

Putting stickers or sheets (e.g. commercially available protective films, peep prevention sheets) on the display might hinder correct operation of

When carrying the product in your pocket or bag, take care not to put the

Organic EL display may have partially dark part or the colors may be

anged if a same image has been displayed for a long time, or the

Organic EL display is made with extremely advanced technology and it

Subjecting an organic EL display to direct sunlight may cause a

malfunction. Take care when placing at the window or outdoor

origintness of backlight is set to too bright, or it has been used for a extremely long time. That is due to property of organic EL display and not a

y have slightly missing pixels or pixels which are always lit. Also, it may

have unevenness of color streak or brightness, or color change depending on direction you're looking. That is due to structure of organic EL display

buch panel close to metals or other conductive materials, as it might cause

Drain the following parts:
Earpiece, Mouthpiece/microphone, Speaker, USB Type-C port, Second microphone, Headset jack, Power key/Fingerprint sensor, Volume key/Zoom key, the cover of microSD memory card/SIM card slot, Camera ring (peripheral part of main camera) If water remains, clothes or bag might get wet or sound might be barely

heard. Drain in the following step 1 Wipe off water remained on the product with a dry cloth, etc.

2 Hold the product firmly and shake it approximately 20 times. then turn upside down and shake it 20 times again When shaking the product, check the safety around you and hold it firmly

3 If water flows out from the inside of the product, wipe it off with

4 Place a dry towel or cloth under the product and leave it for a

It is extremely dangerous to walk while looking at the screen of the mobile phone. Do not make calls or operate a mobile phone while walking or by

· Be careful of sound leakage from earphones in trains or other places with

When using the camera, follow common rules of etiquette regarding camera use.

Product off beforehand.
 When a medical institution has laid down designated areas where use of the

There may be a person with a cardiac pacemaker nearby at a place filled

with people such as in a crowded train. Set "Airplane mode" or turn the

product is prohibited or is not allowed to be brought in, abide by the

You can update the product to the most recent software for optimal

You are charged for the mobile data communication according to your

The update software can be downloaded from the settings menu of the product directly via Internet using a WI-Fi® connection or mobile data

ntract details when accessing the Internet from the product via data

You are recommended to back up your data before updating software.
 For details, refer to "取扱説明書 詳細版 (Full instruction manual)" (Japanese).

ending on the status of your Wi-Fi® connection, the product searches

available networks automatically and the connection may be switched to mobile data communication. In this case, note that unexpected

many people around you. Ask permission if you take photos with your mobile phone camera.

stopping suddenly.

Move to a place where you do not disturb others while you are in

(The internal battery of the product is a lithium-ion battery) Li-ion 00 ■ SIM card

cause a malfunction.

The internal battery is not fully charged at the time of burchase. Charge the internal battery before using the

 Use in very hot or cold environments, for example, when left in an automobile with the windows closed in summer, will cause the internal battery capacity to drop and shorten the available usage time. This will also shorten the internal battery's service life. Try to use the product as far as possible at room temperature. The internal battery gradually discharges after charging even if the product

is not used. The internal battery might discharge completely after long time no use. Charge before using. The internal battery is a consumable part. If the performance of a battery does not recover (e.g. the usable time after each charge has become

extremely short), the battery is at the end of service life, so stop use Battery is built into the product. For replacement, contact "お問い合わせ先 "For inquiries)" on "取扱説明書 詳細版 (Full Instruction Manual)" (J And you might not use the product during certain period of time. Please forewarned. Note that the length of service life varies depending on the usage condition etc. • The internal battery sometimes swells up as they approach the end of its vice life. This is due to the properties of lithium-ion batteries, and is not a

■ Charging equipment Do not wrap the cable of the specified charging equipment (sold)

(Wi-Fi®) functions

■ Internal battery

product for a long time.

separately) around the adapter itself. Do not bend the joint of the plug or connector and the cable of the specified charging equipment (sold separately) forcibly. Do not place heavy objects on an adapter or cable, or do not apply unreasonable force such as pulling. Doing so might cause a

• When unplugging the plug of the specified charging equipment (sold separately) from the outlet, hold and pull the power plug. If you pull the cable, the cable might be damaged.

Notes on using Bluetooth®/wireless LAN

to Japanese domestic standards and FCC standards, and has been

Use of Bluetooth® function and Wireless LAN (Wi-Fi®) function may be

restricted in some countries/regions. Before using the product overseas check the relevant laws and regulations of the country/region you visit.

The 2.4 GHz band used by wireless LAN (Wi-Fi®) and Bluetooth® devices is

Subjecting the product to magnetic or electrical noise may increase noise and prevent it from performing communications (The product is particularly susceptible to noise when it used near a microwave oven).

Using the product near a TV radio or similar appliance may cause reception

interference and disrupt TV images.

The searching might not be successful if there are multiple wireless LAN (Wi-Fi®) access points near to the product or the same channel is being

The communication speed and connectable range vary depending on the distance between communication devices, obstacles and the devices used

1 In the Home screen, slide the screen up \rightarrow [Settings] \rightarrow [System]

shared by various other devices. For this reason, the communication spec

· Do not use the product in places where electromagnetic waves are

generated or near electric products. AV and OA equipment, or other

• The Bluetooth® and wireless LAN (Wi-Fi®) functions of the product conform

2.4 GHz frequency band precautions

as static electricity or a fault, repair, mishandling, etc

The frequencies used by the Bluetooth® and/or wireless LAN (Wi-Fi®) function of the product are in the 2.4 GHz band. In this frequency band, other similar wireless stations, in-plant wireless stations for mobile unit identification that require a license to use, such as factory production lines, specific small power wireless stations that do not require licenses, amateur wireless stations (collectively called "other wireless stations" from here on) are operated in addition to home electrical appliances such as microwave ovens, devices for

Do not forcibly remove or insert SIM card. Be careful not to exert excessive

• You are responsible for any damage caused by inserting your SIM card into

When photographing important occasions etc., take a trial shot and check the shot image to make sure it is correctly shot.

You are not allowed to copy, distribute, publish, modify or edit the data you shot, recorded or downloaded using the product without consent of the copyright holder, except for personal use such as copying or quoting where

on rights of portrait. Note that shooting and recording might be restricted at

provided for under the copyright law. In addition, do not use or modify portraits or names of other individuals without the consent, as it might infringe

some live performances, shows and exhibitions even for personal use.

Be careful about the copyright and portrait right when posting photos you

Please back up important content recorded to the product or downloaded to the product from an outside source. Content recorded to memory on the

product sometimes disappears or is altered by unexpected factors, such

force when inserting the card into your phone.

■ Copyrights and rights of portrait

shot etc. on Internet homepages

■ Backup content on the product

idustrial, scientific and medical devices.

Before using the product, make sure that "other wireless stations" are not in 2. In the event that instances of radio wave interference have occurred between the product and "other wireless stations", immediately either

elocate the product or stop operation of the device (stop the emission of 3. If you are unclear on any points or are troubled by anything, contact "お問 い合わせ先 (For inquiries)" on "取扱説明書 詳細版 (Full Instruction Manual)"

tions between the product and all other Bluetooth® and wireless LAN (Wi-Fi®) devices have not been confirmed. Therefore, connections with all Bluetooth® and wireless LAN (Wi-Fi®) devices are not guaranteed. This product supports security features for wireless communications that are

compliant with the Bluetooth® and wireless LAN (Wi-Fi®) standard

specifications, but the security may not be sufficient depending on th usage environment and configuration. Be careful when making data communication using Bluetooth® or wireless LAN (Wi-Fi®) function. Wireless LAN (Wi-Fi®) has the advantage that it can be freely connected anywhere within the radio wave range, as it uses radio waves for exchanging information. At the same time, there is a risk that a malicious third party may obtain unauthorized access if security settings have not been configured.

You are recommended to configure security settings before using wireless LAN (Wi-Fi®) at your decision and responsibility. The Company assumes no responsibility for leakage of data or information that may occur during Bluetooth®/wireless LAN (Wi-Fi®) communication.
Since Bluetooth® and wireless LAN (Wi-Fi®) functions use the same

frequency band, using the both functions at the same may cause radio wave interference resulting in decreased communication speed or disco from the network. If connection fails, stop using either of the Bluetooth® and ess LAN (Wi-Fi®) functions

32

Please notify us of the production number (IMEI number) for repair requ The production number (IMEI number) can be checked on the product nain unit, sticker on the outer packaging box etc.

nalfunction under the condition that it is used correctly in line with the

in the instruction manual. ② The malfunction or damage is due to unauthorized repair or modification

4. Repair may not be possible depending on the degree of damage

the malfunction of the product.

The Company shall not bear any responsibility for accidents resulting from

use of the product having been connected to unspecified devices 7. Do not accept requests for service calls to the owner's home, place of

This warranty is valid only in Japan.

This warranty guarantees repair free of charge during the period and under the conditions specified on this warranty card. Thus this warranty does not

limit the legal rights of the owner with respect to the issuer of this warranty card (the guarantor) or any other business person or enterprise

Repair and Delivery Support with Cloud

ninal for a long time without worries. This service expands coverage for r monthly charge and details of the service, refer to au/UQ mobile homepage

33

https://www.uqwimax.jp/mobile/plan/option/repair-cloud/ (Japanese) ne contents of services above are subject to change without notice

SIM card

The SIM card is lent to you by your carrier. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected

will be replaced at your expense, which a mainticion is suspected, or in case of theft or loss, contact "お問い合わせ先 (For inquiries)" on "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

Specific Absorption Rate (SAR) of mobile phones

ulations and international guidelines regarding exposure to radio waves. radio waves recommended by a set of equivalent international guidelines. This set of international guidelines was set out by the International Commission on Non-lonizing Radiation Protection (ICNIRP), which is in collaboration with the World Health Organization (WHO), and the permissible limits include a substantial safety margin designed to assure the safety of all persons,

highest SAR value for this mobile phone when tested for use near the head is 1.981 W/kg⁺² and when worn on the body is 1.542 W/kg⁺². There may be slight

differences between the SAR levels for each product, but they all satisfy the This is due to automatic changes to the power level of the device to ensure it only uses the minimum required to reach the network. Therefore in general. the closer you are to a base station, the lower the power output of the device

・"ソニー" and "SONY", or product names, service names, and logo marks

names, company names, and logo marks are trademarks, registered trademarks, or titles of respective companies.

FeliCa is a contactless IC card technology developed by Sony Corporation.
 In context, TM and ® mark may be omitted.
 Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

Security codes/PIN code

The product has various security codes that you can use. The available security codes are as follows. Do not forget the various security

codes that are set as they are necessary for various operations and contracts. Make sure to change the security codes from the initial values to your own numbers

■ PIN code

■ PIN code

be locked. You can unlock the PIN code using PUK code. . Entering PIN code is not required by default state. In "SIM card lock"

however, you can change the setting requiring to enter PIN code.

Note that setting up "SIM card lock" requires entry of PIN code.

When an entry of security code is required for making settings, change the

can change the PIN code to any four- to eight-digit number as necessa

PIN code is not reset even if you execute "Erase all data (factory reset)

■ PUK code the PIN code is locked, you can unlock it by entering the PUK code

https://www.au.com/support/service/mobile/procedure/id/pin-code

If the PUK code is incorrectly entered ten times consecutively, contact "お問い合わせ先 (For inquiries)" on "取扱説明書 詳細版 (Full Instruction Manual)" (Japanese).

This mobile phone can be used in positions other than against your head.

The World Health Organization has stated that "a large number of studies have

https://www.who.int/news-room/fact-sheets/detail/electromagnetic-fields-

Please keep the mobile phone farther than 1.5 cm away from your body by using such as a carrying case or a wearable accessory without including any metals. By doing this, this mobile phone complies with Japanese technical regulations and international guidelines regarding exposure to radio waves.

Notes on Call Charges

When you end a call, make sure to disconnect the call. If you forget to disconnect, the call charges may be higher.

Notes on applications · Be sure to check the security of the app, then install it at your own risk. Some apps might affect operation of other apps or of the entire product.

They might cause virus infection, damage various data, and send out your

location information, usage history or personal information stored in your product via the Internet. The Company assumes no responsibility for any malfunctions that might be

caused by apps you have installed. Repair costs in this case may be charged even during the warranty period. The Company assumes no responsibility for any disadvantage brought to

you or any third party by the apps you have installed. Insertion of a microSD memory card is necessary to use some apps.
 Some apps prohibit the product from entering sleep mode while they are active, or rapidly drain the battery while running in the background. · Operational procedures and screen appearances of the apps preinstalled in

■ Radio Frequency (RF) exposure and Specific Absorption Rate (SAR) When your phone or Bluetooth® handsfree is turned on, it emits low levels of radio frequency energy. International safety guidelines have be through periodic and thorough evaluation of scientific studies.

These guidelines establish permitted levels of radio wave exposure. The

guidelines include a safety margin designed to assure the safety of all

persons and to account for any variations in measurement

the product and those installed by you are subject to change without notice

as a result of version upgrade. In addition, operating procedures described in "Instruction Manual" might differ from the actual procedures.

Specific Absorption Rate (SAR) is used to measure radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions. but because the phone is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this There is no proof of difference in safety based on difference in SAR value.

Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When required, tests are performed when the phone is placed at the ear and when worn on the body. For body-worn operation, the phone has been tested when positioned a minimum of 10 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate Sony Corporation accessor and worn on the body. Use of the phone other than as tested may impact SAR and result in non-compliance with such RF exposure limits. For devices which include "WiFi hotspot" functionality, body-worn SAR measurements for operation of the device operating in WiFi hotspot mode were taken using a separation distance of 10 mm. Use of third-party accessories may result in different SAR levels than those reported For more information about SAR and radio frequency exposure go to: https:// xperia.sony.jp/product/SAR/ (Japanese).

THIS PHONE MODEL HAS BEEN CERTIFIED IN COMPLIANCE WITH THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

This mobile phone model XXXXX has been designed to comply with applicable safety requirements for exposure to radio waves. Your wireless phone is a radio transmitter and receiver. It is designed to not exceed the imits* of exposure to radio frequency (RF) energy set by governmental authorities. These limits establish permitted levels of RF energy for the general dernational scientific organizations through periodic and thorough evalu-f scientific studies. The standards include a safety margin designed to

assure the safety of all individuals, regardless of age and health. The radio wave exposure guidelines employ a unit of measurement known a the Specific Absorption Rate (SAR). Tests for SAR are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands. While there may be differences between the SAR levels of various phone models, they are all designed to meet the relevant guidelines for exposure to radio waves

The highest SAR value as reported to the authorities for this phone mod when tested for use by the ear is 0.81 W/kg*, when worn on the body is 0.66 Wkg* and when WiFi hotspot mode is 0.66 Wkg. For body-worn operation the phone has been tested when positioned a minimum of 10 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate accessory and worn on the body. For devices which nclude "WiFi hotspot" functionality. SAR measurements for the device perating in WiFi hotspot mode were taken using a separation distance of 10 nm. Use of third-party accessories may result in different SAR levels than

* Before a phone model is available for sale to the public in the US, it must be

tested and certified by the Federal Communications Commission (FCC) tha it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (i.e., by the ear and worn on the body) as required by the FCC for each model. The FCC has granted an Equipment Authorization for this phone model with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. While there may be differences between the SAR levels of various phones, all mobile phones granted an FCC equipment authorization meet the government requirement for safe exposure. SAR information on this phone model is on file at the FCC and can be found under the Display Grant section of https://www.fcc.gov/oe ea/fccid after searching on FCC ID PY7-37016L. Additional SAR-related information can also be found on the Mobile and Wireless Forum at https://

the United States, the SAR limit for mobile phones used by the public is 1.6 watts/kilogram (W/kg) averaged over one gram of tissue. The standard incorporates a margin of safety to give additional protection for the public

This paragraph is only applicable to authorities and customers in the Unite

Europe

and to account for any variations in measurements.

margins designed to assure the safety of all persons, regardless of age The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using ardized methods with the phone transmitting at its highest certified level in all used frequency bands. power level in all used frequency bands

While there may be differences between the SAR levels of various phone

models, they are all designed to meet the relevant guidelines for exposure to SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the International Commission on Non-Ionizing

For body worn operation, this phone has been tested and meets RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body. Use of other accessories may not ensure compliance with RF exposure guidelines

In the case where the phone is worn on the body, the highest tested SAR

value is 1.07 W/kg (10g).

a dry cloth etc.
* Face the product downward and push it on a cloth to wipe off the water.
* Turn the upside down and wipe off the water.

couple of hours at room-temperature to dry
* If the product is not dried enough, you can barely the product enough time to dry before use. Use of mobile phones on board is restricted. Follow the instructions of each

30

To prevent ringtone from bothering other people, not only refrain from making a call but also power off or use Silent mode at a movie theater, → [System update] that, follow the onscreen instructions. · In a city area, use in a place where you do not bother people walking

After-sales service ■ When asking for repair r repair, make an inquiry to Repair and Delivery Support Center

During the Repairs will be done based on the terms of services of

We shall repair the product for a charge as requested by Outside the The warranty period is one year from the date you newly purchased the

Before handing in the product for repair, make a backup of the contents of

memory since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents Recycled parts that meet the Company's quality standards are sometimes Your old terminal collected by replacement mobile phone delivery service is

serviced for reuse and recycled as a replacement terminal. Also, parts replaced through after-sales service are collected and recycled by the Company. They cannot be returned to customers. The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse

engineering, decompiling, reverse-assembling), or repaired by an authorized repair office is not covered by the warranty and repair may be The battery built-into the main unit is not covered by free-of-charge repair

■ Performance parts for repair

FCC Statement for the USA

The Company retains performance parts for repair of the main unit and its peripherals for four years after discontinuation of production. "Performance pa for repair" refers to parts required for maintaining the functions of the product.

his device complies with Part 15 of the FCC rules. Operation is subject to the s device may not cause harmful interference This device must accept any interference received, including interference that may cause undesired operation. v change or modification not expressly approved by Sony may void the

ser's authority to operate the equipment.

his equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are signed to provide reasonable protection against harmful interference in a sidential installation. This equipment generates, uses and can radiate radio quency energy and, if not installed and used in accordance with the ructions, may cause harmful interference to radio communications. wever, there is no guarantee that interference will not occur in a particular

this equipment does cause harmful interference to radio or television

ception, which can be determined by turning the equipment off and on, the er is encouraged to try to correct the interference by one or more of the Reorient or relocate the receiving antenna. ncrease the separation between the equipment and receiver.

Foreign Exchange and Foreign Trade Act

Provisions for free-of-charge repair (IMFI number) for repair request

31

2. During the warranty period, we will repair the product free of charge for the

directions given in the instruction manual.

Even if the warranty period has not expired, a fee will be charged for repair

under the following circumstances. (or, repair may not be possible) 1) The product has not been used correctly in line with the directions given

The malfunction or damage is due to negligence in use or handling, or due to an accident. There are signs of the product having been dropped, wet, exposed to humidity, etc.

The malfunction or damage is due to natural disasters (earthquakes, storm or flood damage, etc.), fire, salt damage, abnormal voltage, etc.

. The Company shall have no liability for any damage or loss resulting from

39

46



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation Wi-Fi® is a trademark or registered trademark of Wi-Fi Alliance®

oSD logo, microSDHC logo and microSDXC logo are trademarks of SD-3C, LLC.

• USB Type-C® is a registered trademark of USB Implementers Forum a registered trademark of FeliCa Networks, Inc. · Google and Android are trademarks or registered trademarks of Google

Intellectual property rights

and their subsidiaries is under license.

license for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard (*MPEG-4 video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG-4 or AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained MPEG LA, LLC. (See https://www.mpegla.com). MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson.

• The software installed on the product or part of it may not be altered,

The product is licensed under the MPEG-4 visual and AVC patent portfolio

r-sales service membership program on a monthly basis called "Re livery Support with Cloud" is available for using your au/UQ mobile many troubles including malfunction, theft and loss.

This model XXXXX mobile phone complies with Japanese technical This mobile phone was designed in observance of Japanese technical regulations regarding exposure to radio waves 1 and limits to exposure to

regardless of age and health condition. The Japanese technical regulations and international guidelines define the limits using a unit of measurement known as the Specific Absorption Rate (SAR), which represents the average amount of radio frequency energy absorbed by the human. The SAR limit for mobile phones is 2.0 W/kg. T

used in this manual are registered trademarks or trademarks of Sony Group Corporation or its affiliated companies. All other product names, service









Manufactured by: Sony Corporation

Important items to remember before use Make sure that the cover of microSD memory card/SIM card slot is firmly closed.

Waterproofness/dustproofness is only effective when the cover is securely closed Do not open or close the cover of microSD memory card/SIM card slot if the

roduct or your hands are wet.

o not sink the product in liquids other than tap water (seawater, pool water,

water of hot spring, water with soap, detergent or bath salt contained, alcohol, juice, seasonings, etc.) or do not splash such liquid to the product

Also, do not use in a place where urine of pet animal is splashed. If it is splashed on the product, immediately wash the product with tap water. Do not put the product directly on sand at a beach etc. Sand or other small particles might get inside the earpiece, mouthpiece/microphone, speaker, or

second microphone causing the volume to drop. If sand gets inside of the main unit, it might cause overheating or a malfur Do not leave the product in a humid place such as a bathroom or kitchen for

an extended period of time.

Do not wash the product in a washing machine or ultrasound bath

. Do not immerse the product into a bathtub. The product is not resistant to

The product does not float on water.

Security codes

Initial value A four-digit number chosen by the customer and noted on the application form

vent unauthorized use of the SIM card by a third party, you can set the orduct to require PIN code entry every time the power is turned on. You also need to enter PIN code when setting whether the PIN code entry is required. I

initial value of the security code to your own number and then use it. PIN code is set to "1234" by default state. In "Change SIM PIN", however, you

In case the PIN code is locked, you can unlock it by entering the PUK code. PUK code is an eight-digit number given at the time of purchase, and is printed on the back side of the plastic card on which your SIM card is attached. When using eSIM, refer to au homepage for details.

(Japanese)
After entering the PUK code, you need to set a new PIN code.

been performed over the last two decades to assess whether mobile phones pose a potential health risk. To date, no adverse health effects have been established as being caused by mobile phone use.* Please refer to the WHO website if you would like more detailed information.

and-public-health-mobile-phones Technical regulations are defined by the Ministerial Ordinance Related to Radio Law (Article 14-2 of Radio Equipment Regulations).

*2 Including other radio systems that can be simultaneously used.

Please refer to the websites listed below if you would like to know more etailed information regarding SAR. Ministry of Internal Affairs and Communications website

https://www.tele.soumu.go.jp/e/sys/ele/index.htm https://www.arib-emf.org/01denpa/denpa02-02.html (Japanese) https://www.au.com/english/

https://xperia.sonv.ip/product/SAR/ (Japanese)

telephones, batteries and battery chargers at stores bearing the

logo regardless of brand and manufacturer to protect the environment and reuse valuable recourses.



ile phone model XXXXX has been designed to comply with

Radiation Protection (ICNIRP), which is 2 W/kg averaged over ten (10) gram of tissue (for example European Union, Japan, Brazil and New Zealand):

he highest SAR value for this model phone tested by Sony for use at the ear

37

In cases of exporting or reexporting the products, customers are requested to follow the necessary procedures at their own responsibility and cost.

Please contact the Ministry of Economy, Trade and Industry of Japan or the
Department of Commerce of the United States for details about procedures.

45

ct the equipment into an outlet on a circuit different from that to which Consult the dealer or an experienced radio/TV technician for help.

The products may be subject to the application of the Foreign Exchange and Foreign Trade Act and other related laws and regulations in Japan. In addition, the Export Administration Regulations (EAR) of the United States

translated/adapted, reverse-engineered, decompiled or reverse-assembled and any such actions are prohibited.

card/SIM card slot is securely attached (based on in-house testing). Do not put stickers etc. on the SIM card. Before using the product, thoroughly read "Important items to remember Do not insert SIM card with conversion adapter attached. Doing so might

25

in the 2.4 GHz band.

etooth® function: 2.4FH4/XX8

■ Wireless LAN (Wi-Fi®) function: 2.4DS/OF4

band of mobile unit identification devices can be avoided

5 GHz frequency band precautions

he channels used on the product are as follows

communication system or relay station).

124, 128, 132, 136, 140, 144 ch)

Available channels differ depending on the country/region.
 For use in an airplane, check with the airline company in advance.

before use" to ensure correct use. Failure to follow the contents described in the sections might cause intrusion of water, sand or other foreign material, resulting in overheating, ignition, electric shock, injury or a malfunction. Do not damage the SIM card by using the product in a hot place, dropping into 1 IPX5 equivalent means that the product will maintain its operability as a fire, contacting to the metal parts with foreign object, giving an impact, bendin applying load, wetting, etc. Doing so might cause loss of data or a malfunction

phone even if it is sprayed with water from a 6.3 mm diameter nozzle at a distance of about 3 meters for more than 3 minutes at a rate of about 12.5 liters per minute from any direction.

IPX8 equivalent means that the product will maintain its operability as a

caused by mishandling by the customer are not covered by the warranty.

phone with no water getting inside the main unit even if it is gently submerged in a tank of still tap water at room temperature to a depth of 1.5 meter for about 30 minutes.

IP6X equivalent means that the product will securely maintain its function

Notes on waterproof and dustproof properties

dustproof grade IP6X*3 on the condition that the cover of microSD memory

product has a waterproof property equivalent to JIS waterproof grade (JIS 920) IPX5*1 and IPX8*2, as well as a dustproof property equivalent to JIS

of no grit and dust getting inside the main unit even after it has been placed in an apparatus with grit and dust of diameters of 75 μ m or less and shaken for 8 hours. Since operation of the product on each usage scene was confirmed based on the above assumption, proper operation of the product in every possible condition during actual use is not guaranteed. Malfunctions determined to be

tooth® and wireless LAN (Wi-Fi®) functions of the product use frequencies

The product uses the 2.4 GHz band. FH4 uses FH-SS as the modulation

dulation scheme. The interference distance is about 80 m or les

scheme. The interference distance is about 40 m or less. XX8 uses another

he product uses the 2.4 GHz band. DS-SS and OFDM are used as the nodulation schemes. The interference distance is about 40 m or less.

his means that all bandwidths of 2.4 GHz band can be used, and that

Wireless LAN (Wi-Fi®) function of the product uses 5 GHz band. Using a 5.2/5.3-GHz-band wireless LAN outdoors is prohibited by law (except when communicating with an access point of a 5.2-GHz high-power data

• W53 (5.3 GHz band/52, 56, 60, 64 ch) • W56 (5.6 GHz band/100, 104, 108, 112, 116, 120,

an extended period of little.

Even after draining, water might remain on the product. Although you can use the product, do not place it near things that must not get wet. Also, take care not to wet your clothes, bag, etc.

Drain water if it becomes temporarily hard to hear the sound due to water remaining in the earpiece, mouthpiece/microphone, speaker, or second

Do not spray the product with high-pressure water or submerge it in water

led periods of time, as the product is not designed to withstand

Extreme changes in temperature generates condensation causing a malfunction. Wait until the main unit reaches room temperature before you bring the product from a cold place into a warm bathroom.