

MP935B2 User Manual

About the Manuals

The Portable internet player comes along with this User Guide.

- This User Guide explains standard and advanced features, enabling you to make full use of the Portable Internet Player and troubleshoot problems.

Table of Contents

About the Manuals	1
Table of Contents.....	1
Notice of Copyright	3
Safety Information	4
Disposal Instructions	5
Functional Modes and Features.....	6
Description of the controls.....	8
Getting Started	10
Package contents	10
Powering ON your MP-935B2.....	10
Charging your MP-935B2.....	11
Music Player	11

All Information and specification are subject to change without further notice.

MP-935B2 User Guide

Listen to the Music Player.....	11
To view the Videos	14
File Manager	16
Music Player	18
Video Player	18
Photo Album	19
EBook	25
Recorder	25
FM Radio.....	26
Call records	27
Phone Book.....	27
Phone Devices: Headset & Handfree (Bluetooth Profile: HSP/HFP)	28
Stereo Devices: Audio Streaming (Bluetooth Profile: A2DP/AVRCP)	28
Computer Devices/ All Devices: File Sharing (Bluetooth Profile: OPP)	29
Pairing the MP-935B2 with the Bluetooth Devices	30
How to use MP-935B2 paired with Phone Devices	34
Dial Mode	34
Types of dial mode	34
Dial directly	34
Dial by Phonebook.....	35
Dial by Call Record.....	35
How to use MP-935B2 paired with Bluetooth stereo headset	36

All Information and specification are subject to change without further notice.

MP-935B2 User Guide

How to use MP-935B2 for file sharing.....	38
Object Push Profile (OPP)	38
FM Radio	44
Fine	44
How to use the bluetooth to send the contact message (vCard) to the MP-935B2?	48
How to translate into AVI format.....	52
Firmware Upgrade:	Error! Bookmark not defined.
Glossary	59
FCC Rules for MP-935B2	60

Notice of Copyright

- The whole or part of the manual must not be copied or translated for distribution, and must not be used for commercial purposes without written approval of the company as this constitutes an infringement of copyright. The information contained here has been carefully put together but may be changed due to product function and performance improvements without prior notice. Therefore, the company shall not be liable for any difference resulting from an unnoticed change between the **MP-935B2** and the manual.
- We reserve the right to change the product specification without prior notice.

All Information and specification are subject to change without further notice.

Safety Information

Read the safety instructions carefully before using your MP-935B2.

- Do not use Headphone/Earphones while driving, cycling or operating any motorized vehicle. This may create traffic hazard and may be illegal in some areas. It can also be dangerous to play your Headphones/Earphones at high volume while walking or engaged in other activities. You should exercise extreme caution and discontinue use in potentially hazardous situations.
- Avoid using Headphones/Earphones at high volume. Hearing expert's advice against continuous loud and extended music play. Keep the volume at a moderate level, so that you are able to hear outside sound, and to be considerate of the people around you.
- Keep your player away from sinks, drinks, bathtub, showers, rain and other sources of moisture. Moisture can cause electric shocks with any electronic device.
- Follow these tips to keep your player working well for a long time:

Clean your player with a soft lint free cloth used on glass lenses.

Do not allow young children to use your player or your

computer. Make sure your connectors are the identical shape and size before you connect.

Do not disassemble, crush, short-circuit or incinerate your battery as it may cause fire, injury, burns or other hazards.

Do not disassemble parts of MP-935B2 or exchange the battery of the MP-935B2.

Disposal Instructions

Do not dispose of this device with unsorted waste. Improper disposal may be harmful to the environment and human health. Please refer to your local waste authority for information on return and collection systems in your area.

This device does not support Hot-Plug feature for the micro-SD card, please turn off the device before plug in or out of the micro-SD card slot.

This device support the micro-SD card according with V1.0 agreement, please confirm the device support this micro-SD card before using the micro-SD card.

If you choose to listen to music by Bluetooth Stereo Headset, you can not call someone through **MP-935B2** after plugging the Bluetooth Stereo headset.


Please plug the normal earphone in the **MP-935B2** to

call.

Functional Modes and Features






The **MP- 935B2** is a small, lightweight and stylish Portable Bluetooth Player. It incorporates a Bluetooth feature which can stream music or make calls using the **MP-935B2**. It can support Phone, Stereo or Computer Devices. Other features include a Music Player, Video Player, Phone Book and a FM Player. Powered by a lightweight, rechargeable battery, the **MP-935B2** provides hours of audio and video on the move.

A brief description of the features is listed below:


	Music Player is a MP3 player and playback's the music files stored in MP-935B2 . It can also stream music to your Bluetooth stereo headset device. It Support MP3 /WMA / WAV file format.
	Video Player playback the video files stored in the MP-935B2 .
	Applications it includes modules in MP-935B2 like, File Manager, Music Player, Video player, Photo album, EBook, Recorder, FM Radio, Call Records and Phone book.


All Information and specification are subject to change without further notice.

MP-935B2 User Guide

	Bluetooth it support Phone, Stereo audio or Computer Devices on making phone call/answer, Streaming music files or for file transfer with the MP-935B2
	Settings used to perform all the system settings like set time, date, backlight, volume, language, speaker, key lock, auto power off, check memory status, restore factory setting and show product information in your MP-935B2
	FM Radio connects to the local FM Radio Stations.
	Call Records Consists of all history of the calls made on your MP-935B2 , so you can call out by the call records by the normal earphone.
	Phone Book has the details of the contacts.




Description of the controls



1		Turn on (press and hold)/ off (press and hold). After the startup is complete, press it to go back to previous menu level
2	Menu	1. Press Menu button Pop-Up the option menu. *2. In the main interface, press to pop the soft key pad. *3. In the main interface, press and hold to enter MIC recorder. In the FM playing, press and hold to enter FM recorder.

All Information and specification are subject to change without further notice.

MP-935B2 User Guide

3	Vol-	1. Adjust the Volume to lower level. *2. In the date and time setting mode, single click Next is decrease the date & time step by step. *3. Switch between the search list table and the name list table in Phone book.
4	Vol+	1. Adjust the volume to a higher level. *2. In the date and time setting mode, single click Pre is increase the date & time step by step. *3. Switch between the search list table and the name list table in Phone book.
5		1.To scroll the menu in backward direction and to go up in the menu list *2. In the soft keyboard mode, single click or press and hold Pre button. The flash cursor moved by row mode.
6		To select or confirm an item.
7		1. To scroll the menu in forward direction and to go down in the menu list *2. In the soft keyboard mode, single click or press and hold Next button. The flash cursor moved by column mode.
8	Reset	Resets the player when you press the reset button with a small pin.
9	MICRO-SD Slot	To hold the MICRO_SD Card

MP-935B2 User Guide

10	Earphone Jack	For connecting the Earphones. Insert the Jack pin until it clicks it the place. You cannot listen to the music if it is not connected properly.
11	USB/Power terminal	To connect the USB terminal to transfer music and video files or to connect the power adopter for charging.
12	Speaker	On the backside of the MP-935B2. To listen to the music without earphone.

Getting Started

Package contents

Your **MP-935B2** package includes:

- MP-935B2
- Earphone
- USB Cable
- User Manual

Powering ON your MP-935B2

To Power on your **MP-935B2**, press and hold the Power key.

After the startup is complete, you will see a welcome

All Information and specification are subject to change without further notice.

screen and then show you the Music Player mode.

Charging your MP-935B2

Your **MP-935B2** comes with a rechargeable battery. To charge the battery, you can use the PC USB port to charge your **MP-935B2**, connect the USB cable to your **MP-935B2**, then connect the other end of the USB cable to the USB port on your PC. It takes about 4 hours to fully charge up the battery. Or you can buy the AC adaptor (output: 550-750mA) yourself to charge your MP-935B2.

Note: Use the same method above to do the file transfer from PC to your **MP-935B2**; once the PC and the **MP-935B2** have been connected and act as Mass Storage device you can simple transfer file between them.

Music Player

Music Player is a MP3 player and plays back the music files stored in **MP-935B2**. You can download music either from the micro-SD card, through the USB of your PC, or through Bluetooth Devices, like phone, pc or MP3/MP4 player etc. [Support for the micro-SD card up to 2GB]

Listen to the Music Player

Select the Music Player from the main menu. Once you are in the Music Player mode you will be connected to the

last played song. Using the \updownarrow or \downarrow buttons to select the song. To view the pop-up menu, press the **Menu** button. To return to the previous menu at any time press the ⏏ button.

The pop-up **Menu** contains:

Minimize – Back to the main interface.

Stop – Stops the music which is being played

Pause – Pause the music which is being played

Play Mode – You have options to repeat the song being played

EQ mode – you can select the following preset Equalizer modes; Normal, Pop, Rock, Jazz, Classical or custom (Use the **Vol-** / **Vol+** / \updownarrow / \downarrow buttons to do the adjustment for the frequency dB level, and lastly use ⏏ button to




save the setting and return to the previous menu)

Bluetooth Stereo – Connects to the Bluetooth stereo headset available to listen to music.

Browse – Search for your favorite song according to some preset category.

Exit – Takes you back to the main menu.

To delete a music file, please select Application then go to File manager option and go to the folder where the music file you want to delete was stored. Then press the **Menu** button, this will pop up the delete menu. Select the required option.



All Information and specification are subject to change without further notice.




Video Player



Video Player plays back the video files stored in **MP-935B2**. You can download video from the PC through USB, the micro-SD card.

Support AVI format, other formats needed to convert into AVI format, and the detail information, please refer to the **"How to translate into AVI format"**.


If you download *.AVI file from Internet, and the MP3 player can't support to play, please use the AVI converter tool to convert the file into the corresponding screen size (240*320) and the frame (≤ 15 fps) which is supported by MP3 player.

To view the Videos

Select the Video Player from the main menu. Once you are in the Video Player mode you will see the list of video files stored. Use  and the  buttons to highlight the video file you wish to play back and press  button to select the video file from menu list.


To pause the video press the  button and press the  button to start playing again.

To play next video file press the **Next** button

To return to the previous main menu press the  button.



To delete a video file, please select Application from main menu, then go to File manager option and go to the folder where the video file you want to delete was stored. Then press the **Menu** button, this will pop up the delete menu. Select the required option.



Applications

Applications let you customize the settings of the **MP-935B2**. Select the Applications from the main menu by pressing the **Menu** button. It includes the following categories:

File Manager – has the information about the Internal and External memory. It lets you access the file folder for various file types that you can store and access the particular file from there directly.



All Information and specification are subject to change without further notice.

Music Player- is a MP3 Player please refers to the Music player section for detail.

Video Player - Plays back the video stored in the video player, please refer to the Video player section for details

Photo Album, lets you view photos stored in the **MP-935B2**, please refer to the Photo Album section for details.

EBook – lets you store your favorite EBooks, please refer to the EBook section for details.

Recorder – helps you record music from the FM Radio or from the Microphone and contain the Record List, please refer to the Record section for details.

All Information and specification are subject to change without further notice.

<p>FM Radio – connects to the local FM radio station, for the details please refer to the FM section.</p> <p>Call Records – Has the details of the calls, please refer to Call Records section for details.</p> <p>Phone Book – Contains the list of the contact details, please refer to the Phone Book section for details.</p>	
--	--

File Manager

The information regarding the Internal and External memory can be found here. Select the File Manager from the Applications menu.

Music Player

Please refer to the description on page××

Video Player

Please refer to the description on page××

Photo Album

Photo Album lets you view photos, either from micro-SD Card you have inserted into your **MP-935B2**, or from the internal storage it supports JPG fine format. You can also insert photos through Bluetooth Devices. Once in the Photo Album you can get access the pop-up menu by press the **Menu** button, it includes:


Set Caller ID Photo, sets the selected photo in **MP-935B2** for a particular Caller ID by selecting the VCard store in the **MP-935B2**. You can know who is calling you when the Bluetooth phone paired with MP-935B2 has phone calling.

Thumbnail, displays a miniature of the pictures and photo in **MP-935B2**

Property, gives the details like name, size and modify time of the photo file

Set Caller ID Photo:

During viewing the Photo




All Information and specification are subject to change without further notice.

MP-935B2 User Guide

you can set the particular photo as the Caller ID Photo for particular contact in the phone book. This can be done directly as the screen shown below when the contact person you wish to set to the Caller ID Photo is already in the Phone book contact list else you need firstly to add in the vCard to the phone book as describe in below section.

Once in the Photo Album you can get access the pop-up menu by press the **Menu** button, from the pop-up menu select the Set Caller ID Photo option then you will see the Phone book screen as shown. Press the **▶||** button to Select the contact in the phone book directly from here to match it to the selected photo that you wish to be the Caller ID Photo for





All Information and specification are subject to change without further notice.

MP-935B2 User Guide

this contact.(If there is no name list, you need add the contacts first. The contacts support vCard format that is a file format standard for electronic business cards and often attached to electronic phone book or e-mail contacts messages. Add vCard please reference page ××)

Use the **Vol-** / **Vol+** / **↕** / **↕** buttons to do the adjustment the cursor, select the name you want. Confirm it.

You will see this screen once you manage to set the particular photo to be the Caller ID Photo to the particular contact in the phone book.




For the case when the phone book list was empty for the start, you need to add the vCard to the phone book before

All Information and specification are subject to change without further notice.

you can set the particular contact to a photo in the photo album. You can add the vCard as follow:

Enter to Phone Book menu you will see this screen when the phone book list was empty. Press ► button to enter the interface of File manager. As following:



Select the option where the vCard was stored, for example select the Internal memory option to get access to the folder where the vCard was stored.




MP-935B2 User Guide

Enter Internal memory interface, select the INBOX folder. Press **▶||** button, add the INBOX folder to Phone book, and return the main interface.

Once the vCard is added you can set the Caller ID photo to a particular contact directly from the photo album as describe above, please refer to Set Caller ID Photo section above.




In the Phone book, select a name and click the **Menu** button, it will pop up the interface as the right.




Finish adding VCard file, enter Phone book again. Display as following. Press **Vol+** or **Vol-** button, switch between search table and name list table. Display as following:


All Information and specification are subject to change without further notice.



Note: There are two methods to load the vCard into the **MP-935B2**, one is through PC and another is through Bluetooth enable hand phone's phone-book to the **MP-935B2** by Bluetooth connectivity. Please refer to the user manual of the particular hand phone as different phone has different method of operation on this feature.

To delete a photo file, please select Application then go to File manager option and go to the folder where the photo file you want to delete was stored. Then press the **Menu** button, this will pop up the delete menu. Select the required option.

To go back to the previous menu at any time press the  button.



EBook

EBook helps to store your favorite books. To access the EBook application, select it from the Applications menu. The EBook supports Txt file format. One enters to the EBook you will be connected to the last page you have read.


To view the pop-up menu presses the **Menu** button.

Go to first page, Jump to the first page.

Back ground picture, Set the background picture by your favorite picture.

Front color, Display the font color.

Auto scroll, It can auto scroll the page, when you reading. The auto scroll's speed include: Fast / Middle / Low.

A screenshot of a mobile application interface. The background is a dark, textured image with white text. A green semi-transparent menu is overlaid on the right side of the screen. The menu has a title bar with a blue star icon and contains four options: 'Go to first page', 'Back ground picture', 'Font color', and 'Auto scroll'. The 'Go to first page' option is currently selected, indicated by a green highlight. At the bottom of the screen, there is a green progress bar and a blue percentage '33.9%'. The top status bar shows the time '13:28PM' and a blue star icon.

Recorder

To access the recorder, select it from the Applications menu. The categories of the recorder are as below:

All Information and specification are subject to change without further notice.


FM record, use to record music from the local FM stations in WAV format.

Mic recorder, Use to record voice from the Microphone in WAV format.

Record list, List of the files recorded from FM recorder or Mic recorder in WAV format.

Use \updownarrow and the \downarrow buttons to select the recorded file and press the \triangleright button to select the recorded WAV file to play back.

To return to the previous menu at any time press the ⏮ button.



FM Radio

Please refer to the FM radio description.


Call records

Call records contains the records of all the calls made, received and missed ones. Select the call record and press the **Menu** button to access the pop up menu which is as follows:

Delete, removes the selected record.

Delete all the records, removes all the records from the list.

Detailed information, Lists out more information about the calls



Phone Book

Phone Book includes the details of the contacts. To scroll the list of the contacts use the **PRE** and the 'Next' and **Next** button to select it. Please refer to the Phone Book section for more description.

Bluetooth

Bluetooth specification: Bluetooth 2.0 /EDR, Class 2

All Information and specification are subject to change without further notice.

The Bluetooth is used different functions here after pairing **MP-935B2** with different Bluetooth Devices:

Phone Devices: Headset & Handfree

(Bluetooth Profile: HSP/HFP)

MP-935B2 is used here to be a Bluetooth Headset pairing with Bluetooth mobile phone. It can let you never miss a call while listening to music, auto pause/resume playing song while there is in-coming call, and dial out function without getting phone out of pocket.

MP-935B2 also provides the call records and phone book for a quick reference to support dialing out function. It also owns the Caller-ID Photo that is the same function as the mobile phone to know who is calling you for great convenience.

Stereo Devices: Audio Streaming

(Bluetooth Profile: A2DP/AVRCP)

The Bluetooth is used here to wireless stream the music from the **MP-935B2** through Bluetooth enabled stereo headset, speaker and car kit etc.

Bluetooth stereo headset is also used to get calls from

your Bluetooth mobile phone when listening to your favorite music in MP-935B2. You can never miss a call when listening to the music.

Bluetooth stereo headset (Supporting AVRCP) is used wireless music remote control to MP-935B2: play, pause, stop, next, and previous.

Note:

- If bluetooth Stereo headset pair with Bluetooth Mobile Phone, and you want to answer a call through bluetooth stereo headset, the MP3 player will stop playing music, After answering the call or end call, the bluetooth headset will receive the music automatically from MP3 player again, and you can use the bluetooth headset to listen to the music in MP3 player again.




Warning: if you want the bluetooth stereo headset can answer the call, the MP3 player can't pair with the bluetooth mobile phone.

Computer Devices/ All Devices: File

Sharing (Bluetooth Profile: OPP)

The Bluetooth is used here to share digital contents (song, video, photo, e-book, document, and vCard etc.) between Bluetooth enabled devices like Lap-top, PC, mobile phone,

and other Bluetooth media player etc.


Access the Bluetooth mode use using  and  buttons to select it and then press the  button to enter to Bluetooth mode from the main menu. Once you are in the Bluetooth mode, you will get the menu as shown below.

Activated, turn on and off your Bluetooth

My Devices lists the categories you can search.

Visible, will show the visibility of the Bluetooth.

My Device name shows the name of the device



Pairing the MP-935B2 with the Bluetooth Devices

Activated the Bluetooth; in the **MP-935B2** and the Bluetooth Devices (Please refer to the user guide of your Bluetooth Devices and turn on to pair mode). Then select the **My Devices** and you will see the options listed below.

Phone Devices will search for the new phone devices enabled with Bluetooth.

Stereo Devices, will look for the stereo devices enabled with Bluetooth

Computer Devices will look for the Computer devices with Bluetooth enabled


All Devices, will look for the devices which are Bluetooth enabled



Go to **All Devices**, and select **search new device** in the next menu screen. This will list out the devices available. Next choose the device that you wish to pair to by using **↶** and **↷** buttons to highlight it and then press the **▶||** button to select it. This will prompt you if you want to pair with the selected device as seen below:

MP-935B2 User Guide


Press the ► button to confirm the pairing with the device (Bluetooth headset or Mobile phone) found.



This will ask you for the password to be entered. To scroll the numbers row wise press the **PRE** and to move column wise press **NEXT** button. Now it will list the name of the headset that is paired. Finish pairing, should be connected each other.

Note:

Pairing Phone Devices: MP-935B2 and Phone Devices should be both keyed in the same password with 4 numbers, like 8888.



All Information and specification are subject to change without further notice.


MP-935B2 User Guide


Pairing Stereo Devices:
MP-935B2 should be keyed in the password of your Stereo Devices.


Pairing others: It depends on Bluetooth Devices. Please refer to the user guide of your devices.


The password of MP-935B2 is 8888.

The password of i.Tech Clip R35 is 8888 (i.Tech Clip R35 is the example for the Bluetooth headset).

After pairing successful, connect with the phone device. If connect is successful, the icon of Bluetooth in the inform bar is changed for .



After pairing successful, connect with the stereo device. If connect is successful, the icon of Bluetooth in the inform bar is changed for .



How to use MP-935B2 paired with Phone Devices

Dial Mode

Now that the Pairing is done with your Bluetooth Phone Devices (Mobile Phone with HS/HF Profile) you can also use it to dial, and to receive phone calls and talk over your **MP-935B2** (Bluetooth Headset).

Types of dial mode


You can use the **MP-935B2** to make a call in three ways; Dial directly, Dial by phonebook, and Dial by the track record. All the three Dialing modes are explained below;

Dial directly

From the main menu of the **MP-935B2**, press the **MENU** button, you will get the soft keypad as seen below.

Enter the phone number you wish to call. To scroll the numbers row wise press the **Next** and to move column wise press **PRE**. To dial the number entered select the Call key and press the ► button

To stop the call made press the ☎ button.



Dial by Phonebook

From the main menu select the Phone Book application. Once in the Phone Book, it will list the details of the contacts available. To scroll the name list use the **Next** or **PRE** buttons. To call the highlighted button, press the ► button. To end or cancel the call, press the ☎ button.

Dial by Call Record

From the main menu select the Call Record application. The Call record lists the details of the calls. To scroll the name list use the **Next** or **PRE** buttons. To call the highlighted button, press the ► button. To end or cancel the call, press the ☎ button.

In all the three dialing modes, in between a conversation, press the **MENU** button to get the below pop-up menu;

Dial Last Number– Dial the last number of record list.


End Call– this will disconnect the call.

Mute– This will mute the volume

Audio Transfer to AG– Switch to hand-phone.

DTMF Input– When you need input the number for extend phone or get prompting message. Select it.

Dial Key board, this will pop-up the soft keypad



How to use MP-935B2 paired with Bluetooth stereo headset

Now to connect to the Bluetooth stereo follow the steps


All Information and specification are subject to change without further notice.

listed below:

When you are listen the music, click the **MENU** button and you will get a pop-up menu as seen in the screenshot. Select the **Bluetooth stereo** by using \uparrow and \downarrow buttons to highlight it and then press the \rightarrow button.



Select the Bluetooth stereo headset that you want to stream the music to.




For the case, there is no stereo device, enter this interface. You need to search new stereo devices. If there is a stereo device paired, you can connect it directly.



All Information and specification are subject to change without further notice.

MP-935B2 User Guide

The pairing process is same as up description. Then input the pairing code and connect.



It will be connect and start streaming the music from the **MP-935B2** to the Bluetooth headset.



How to use MP-935B2 for file sharing

Now to connect to the Bluetooth enabled Devices; like Mobile Phones, PC or Laptop with OPP to transfer MP3, JPEG photo files (OPP Profile) please follow the steps listed below:

Object Push Profile (OPP)

The **MP-935B2** can also be used to transfer MP3, JPEG photo files using the Bluetooth enabled Devices, like Mobile Phones, PC or Laptop. To do this, first the

All Information and specification are subject to change without further notice.

Bluetooth device has to be paired with the **MP-935B2**.
To perform this, follow the steps below:

Turn on the Bluetooth of both the Mobile phones and the **MP-935B2**.

Once the file is selected from the mobile phone that has to be transferred, go to the menu of it and select the **send via Bluetooth** (This depends on the device you are using for the OPP/file transfer);

The file will be send to the **MP-935B2** once it accepts the prompt.


The file will be saved in the **Inbox** folder of the File Manager under Application section from main menu (See below section).




The transfer can also be done from **MP-935B2** to the Mobile phone or other devices that are Bluetooth OPP

Profile enabled.

Go to **Application** from the main menu, select the **File Manager** option then select the memory location where the MP3 file is stored.




Select the Internal Memory option, and select the folder where the Mp3 music was stored. Highlight the Mp3 file (other files) that you want to transfer to the Mobile Phone that you have already paired and connected to. Press and Hold the Menu button, a pop up menu will appear and select the **Send via Bluetooth** option from it.



Lastly, a **More Device** pop menu will show when the device is connected via Bluetooth. Select the device to which the highlighted file should be transferred.

Once you have selected the device name, the device will be notified, that the file is going to send to the device and whether it wants to accept or cancel. If the device accepts it, the file will start transfer from the **MP-935B2** to the device selected above.



Settings

Settings lets customize the settings of your **MP-935B2**. Select the **Settings** from the main menu and you will see the settings menu. It includes the following categories:

All Information and specification are subject to change without further notice.

Time and date – Allows you set the time and date.

Backlight - Allows you set the duration the backlight should be switched on.

Music volume – Allows you to adjust the volume of the music

Voice volume – Allows you to adjust the voice volume


Language – Used to select the desired language.

Memory status – Has information regarding the usage of the memory

Key lock – Helps to lock or unlock the keypad

Restore factory settings – Allows you to restore the factory settings

Product information – Contains the information regarding the **MP-935B2**, like the software version, Bluetooth address, product model name and produced date.



Note:

Adjust the music volume & Voice volume is not influence each other.

Set **Time and date** as following:

Mode – Consists of two kind modes (12H/24H).

The special operate:

Settings interface operating describe as following.

Vol+ : Press **Vol+** button to increase the number.

Vol- : Press **Vol-** button to decrease the number.

⏮ : Press **⏮** button to skip previous item.

⏻ : Press **⏻** button to return. Press and hold it to be powered off.

⏭ : Press **⏭** button to skip previous item.

▶|| : Press **▶||** button to save time and date value and then return to settings interface.



FM Radio

FM Radio automatically tunes to the available FM Station when selected. To view the pop up menu press the **Menu** button. You will see a screen as below;

Minimize – Back to the main interface.

Channel list – lists the channels available.

Fine – Allows you to fine tune the channel

Auto search channel – Searches the channel automatically.

FM region – Select the desired region.

FM sensitivity – Shows how sensitive the FM is

Exit – Exits from the FM Radio



Fine

This is used to fine tune the selected channel. To Fine

All Information and specification are subject to change without further notice.

tune the channel use the '**PRE**' and '**Next**' buttons. Then press the **Menu** button to save the fine tuned channel.

Call Records

Call records contains the records of all the calls made, received and missed ones. Select the call record and press the **Menu** button to access the pop up menu which is as follows:


Delete, removes the selected record.

Delete all the records, removes all the records from the list.

Detailed information, Lists out more information about the calls

Note:

If you want to save the call records into phone book, you need to save them from your mobile phone first and transfer the contacts (vCard) to phone book in MP-935B2 by file sharing of Bluetooth function.



Phone Book

Phone Book includes the details of all the contacts. Using the Bluetooth device that you are connected you can also

All Information and specification are subject to change without further notice.



access the phone book to call.

To scroll the list of the contacts use the '**PRE**', '**Next**' and **▶||** button to make the call.

Note: If your phone book is empty, then you need to add the vCard to **MP-935B2** to get the contact list, please see the section, Set Caller ID Photo above on how to add the vCard to the **MP-935B2** so to get the contact list under the phone book.(Page 18)

Finish adding VCard file, enter Phone book again. Display as following. Press **Vol+** or **Vol-** button, switch between search table and name list table.

Once your phone book is not empty then you can make a call by select the name from the list, then press **▶||** button to pop up the interface as




All Information and specification are subject to change without further notice.

MP-935B2 User Guide


shown. You can call out directly now by press ► button.

At the Phone book interface, select a name and click Menu button pop up the option dialog.



In the main interface, click Menu button, pop up the following interface:

Using ▲ and ▼ buttons to highlight the number you need and then press the ► button. When you finish input the phone number, select the call and press ►, and call out.




How to use the bluetooth to send the

All Information and specification are subject to change without further notice.

contact message (vCard) to the

MP-935B2?


1. Select one contact in your mobile, and then go to blueooth mode to send the contact message to MP-935B2.
2. When the MP3 player prompt "Receive data from xxx" (xxx means the mobile model), and press ►|| button to receive the data from the mobile, then press ►|| button again to add the contact message to the Phone book mode directly.
3. Users can go to the Phone book mode to view the contact which you send.
4. If message "Receive data from xxx" (xxx means the mobile model) will be prompted for several seconds, the message will be disappear automatically or when prompting "Receive data from xxx" (xxx means the mobile model), users press ⏏ key to exit from the prompt message, users need to go to submenu mode of Phone book mode run "Load vCard" function to add the contact from the INBOX folder of the Internal memory mode.



Note: *If there has no contacts in Phone book mode, press ► key to go to the File manager mode directly, where users can find the desired contacts to add to the Phone book mode.

*If there have the contacts in Phone book mode, please select one contact first, then press ► key to go to the File manager mode.

Press ► key to enter into File manager, then selection internal memory or External memory option, display as below:




Select INBOX folder and use Prev/Next key to choice the

All Information and specification are subject to change without further notice.

vCard document which you want to import, display as below:




Press **►||** key to import the document, the prompts "Loading vCard and Exit" and "Load successfully" display on the screen and return to Phone book interface, then press **►||** key to browse, display as below:



Press **Vol+** or **Vol-** button to switch between the letter search and the contact person then press Prev/Next key to select one contact person and press **►||** key to look over, display as below:

All Information and specification are subject to change without further notice.


Selection on contact person, press MENU key to select delete/clean/import vCard document/setting the incoming telegram picture and so on other operation.



How to translate into AVI format

1. Switching the video file into AVI format through the conversion tool
This player only supports the AVI format file in video mode.
2. How to use the conversion tool :
After installing Media Coder SE, double click the icon on the desktop.


MP-935B2 User Guide



This is the Simple Mode interface, you can select other mode through below ways:

Selection User Interface Mode under Option, then selecting Normal Mode, the screen display as below:


MP-935B2 User Guide



Click "Add file" to add the file directly, and then click "... " to set the output route on the top right corner of output route option.


All Information and specification are subject to change without further notice.

MP-935B2 User Guide



After settings, click the down left to set “Picture” option, the screen display as below”

MP-935B2 User Guide




Resize: Please choose the confirm frame behind the Resize firstly, then you can select you desired resize, you can set the resize as below:

176*144,208*176,320*240.

Frame Rate: If the resize is 176*144 or 208*176, you can set the frame rate is 24.000; under the state than the resize is 320*240, you can set the frame rate is 15.000.

Click the "Audio" option on the setting options, the screen display as below:


MP-935B2 User Guide



Source: Setting as Lame MP3 Decode only.

After setting the picture and the Audio option, click "Start" to convert the audio file, the output format is AVI format.

All Information and specification are subject to change without further notice.



3. Add to video list from your player.

Copy the audio files which you have converted to your player, please follow the below instructions:

Application→File manager→XXXX memory→Video File→Option menu→Add to video list→PLAY key. If the option is "Delete from video list", that is stand for the file have been added to video list, then return to main function list.

4. Play the Video file on your player

In the main menu, selection Video player mode and entering into video playing list, selection you desired playing Video file, and press PLAY key to play. During the progress, you can do fast-forward, fast-rewind, pause,

All Information and specification are subject to change without further notice.

adjusting the volume and other operations

Glossary

Bluetooth

is an industrial specification for wireless personal area networks (PANs). Bluetooth provides a way to connect and exchange information between devices such as mobile phones, laptops, PCs, printers, digital cameras, and video game consoles over a secure, globally unlicensed short-range radio frequency. The Bluetooth specifications are developed and licensed by the Bluetooth Special Interest Group.

<http://en.wikipedia.org/wiki/Bluetooth>

Ebook

An e-book (for electronic book: also eBook, ebook) is the digital media equivalent of a conventional printed book. Such documents are either read on personal computers, or on dedicated hardware devices known as e-book devices or e-book readers.

An e-book is a specialised type of e-text.

<http://en.wikipedia.org/wiki/E-book>

Pairing

Normally, two Bluetooth devices always need to be initially paired before they can exchange data. The term, pairing, usually means that two devices are exchanging protected passkeys. Once paired, all information sent over the Bluetooth link is encrypted and will only be able to reach devices that are authorized to do so by the pairing process. In certain instances it may not be necessary to conduct the pairing procedure.

<http://www.bluetooth.com/Bluetooth/Apply/Troubleshooting/>

FCC Rules for MP-935B2

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

All Information and specification are subject to change without further notice.

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer of an experienced radio/TV technician for help.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, user and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or televising reception.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

