

Wireless Controller for GameCube™ and Wii™



Please read this user's guide before using your new Controller.

Package contents

- Controller
- User's Guide
- Receiver
- QuickStart

Features

- Ergonomic design fits comfortably in your hands
- Enables you to move freely up to 30 feet (9.14m) away while playing

1 Install batteries

1. Open the battery compartment covers.
2. Install 1 AAA battery to each compartment, matching the polarity symbols (+ and -) marked inside.
3. Replace the battery covers.

Battery Notes:

- Dispose of batteries promptly and properly. Do not burn or bury them.
- Use only fresh batteries of the required size and type.
- Do not mix old and new batteries, different types of batteries (alkaline, or rechargeable), or rechargeable batteries of different capacities.
- If you do not plan to use the controller for more than one week, remove the batteries. Batteries can leak chemicals that can damage electronic parts.





Image 1

2 Connect receiver and controller

GameCube™ and Wii™

1. Insert the receiver's GameCube plug into the socket on the Gamecube or Wii console.

2. Turn on the controller. The controller's RX LED flashes and the receiver's RX LED lights up steadily.




Wii classic

1. Insert the receiver's Nunchuk plug into the external extension connector of the remote.
2. Turn on the controller. The controller's RX LED flashes and the receiver's RX LED lights up steadily.

Manual connection

If the controller does not automatically connect to the receiver, follow these steps to connect manually.

1. Press CONNECT on the receiver. The RX LED flashes quickly.
2. Press the START and LZ buttons on the controller at the same time until the RX LED lights up steadily.



Specifications

Power Source 2 AAA Batteries (not included)
Control Distance Up to 30 ft (9.14 m)
Frequency 2.4 GHz
Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.


Should a problem occur that is covered by this warranty, take the product and the sales receipt as proof of purchase to the place of purchase. Ignition, L.P. will, at its option, unless otherwise provided by law: (a) repair the product without charge for parts and labor; (b) replace the product with the same or a comparable product (which a refund is made, become the property of Ignition, L.P.); and (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of Ignition, L.P. Service, repair or replacement parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product after the expiration of the warranty period.

IGNITION, L.P. EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHETHER EXPLAINED OR IMPLIED, IN ACCORDANCE WITH THE LAW OF THE STATE OF TEXAS OR ANY OTHER STATE OR PROVINCE.

EXCEPT AS DESCRIBED ABOVE, IGNITION, L.P. SHALL HAVE NO LIABILITY OR RESPONSIBILITY FOR THE PRODUCT OR ANY OTHER PERSON'S ACTIVITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGE RESULTING FROM NEGLIGENCE AND VILLCOSOF TIME, DATA, PROPERTY, REVENUE, OR PROFIT AND ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF IGNITION, L.P. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. You may contact Ignition, L.P. at:

309

For product support, call
1-863-1542

 Protect the environment by recycling used electronics. Go to E-CyclingCentral.com to find an electronic recycling center near you.

GameCube and Wii are trademarks of Nintendo of America, Inc. This product is not sponsored, endorsed or approved by Nintendo.

© 2009 Ignition, L.P. All rights reserved.
Gigaware is a registered trademark used by Ignition, L.P. Printed in China 26-1557