


315 MHz Key Fob Transmitter



Note: Button configuration may vary from illustration.

FCC Warning

*This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

*Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.


*This device transmits a radio frequency signal. The radio frequency signal should not be modified.

Care and Maintenance

- 1) Do not immerse transmitter in water. If transmitter gets wet, dry immediately.
- 2) Avoid use of corrosive or abrasive materials that may damage plastic parts and corrode the electronic circuit.
- 3) Do not subject transmitter to extreme force, shock, temperature or humid conditions. This may result in malfunction, a shorter life span, or damage to batteries.
- 4) Do not tamper with internal components. This may result in improper operation or product failure.
- 5) See diagram below for battery replacement.

SIDE VIEW

INSIDE VIEW



Note: Replace only with #2032 coin cell battery

Specifications

Operating Voltage	3VDC
Operating Temp	-20 C to +70 C
RF Frequency	315 Mhz
Oscillator	Crystal Tuned
Dimensions:	
Height	56.77mm (2.235")
Width	35.18mm (1.385")
Depth	8.43 mm (0.332")
Weight:	0.4oz