


802.11ax-HE 20 – Ant 1

Channel 117 (6535MHz)

The Reference Level



The Mask Data



Channel 153 (6715MHz)

The Reference Level



The Mask Data



Channel 181 (6855MHz)

The Reference Level



The Mask Data



802.11ax-HE40 – Ant 1

Channel 3 (5965MHz)

The Reference Level



The Mask Data



Channel 51 (6205MHz)

The Reference Level




The Mask Data



Channel 91 (6405MHz)

The Reference Level




The Mask Data



802.11ax-HE40 – Ant 1

Channel 123 (6565MHz)

The Reference Level




The Mask Data



Channel 147 (6685MHz)

The Reference Level



The Mask Data



Channel 179 (6845MHz)

The Reference Level




The Mask Data



802.11ax-HE80 – Ant 1

Channel 7 (5985MHz)

The Reference Level



The Mask Data



Channel 55 (6225MHz)

The Reference Level




The Mask Data



Channel 87 (6385MHz)

The Reference Level




The Mask Data



802.11ax-HE80 – Ant 1

Channel 135 (6625MHz)

The Reference Level




The Mask Data



Channel 151 (6705MHz)

The Reference Level



The Mask Data



Channel 167 (6785MHz)

The Reference Level



The Mask Data



802.11ax-HE160 – Ant 1

Channel 15 (6025MHz)

The Reference Level



The Mask Data



Channel 47 (6185MHz)

The Reference Level



The Mask Data



Channel 79 (6345MHz)

The Reference Level



The Mask Data



802.11ax-HE160 – Ant 1

Channel 143 (6665MHz)

The Reference Level



The Mask Data



802.11be-EHT20 – Ant 1

Channel 1 (5955MHz)

The Reference Level



The Mask Data




Channel 49 (6195MHz)

The Reference Level



The Mask Data



Channel 93 (6415MHz)

The Reference Level



The Mask Data



802.11be-EHT20 – Ant 1

Channel 117 (6535MHz)

The Reference Level



The Mask Data



Channel 153 (6715MHz)

The Reference Level



The Mask Data



Channel 181 (6855MHz)

The Reference Level



The Mask Data



802.11be-EHT40 – Ant 1

Channel 3 (5965MHz)

The Reference Level



The Mask Data




Channel 51 (6205MHz)

The Reference Level



The Mask Data




Channel 91 (6405MHz)

The Reference Level



The Mask Data



802.11be-EHT40 – Ant 1

Channel 123 (6565MHz)

The Reference Level



The Mask Data



Channel 147 (6685MHz)

The Reference Level



The Mask Data



Channel 179 (6845MHz)

The Reference Level




The Mask Data



802.11be-EHT80 – Ant 1

Channel 7 (5985MHz)

The Reference Level



The Mask Data



Channel 55 (6225MHz)

The Reference Level



The Mask Data



Channel 87 (6385MHz)

The Reference Level



The Mask Data



802.11be-EHT80 – Ant 1

Channel 135 (6625MHz)

The Reference Level



The Mask Data



Channel 151 (6705MHz)

The Reference Level



The Mask Data



Channel 167 (6785MHz)

The Reference Level




The Mask Data



802.11be-EHT160 – Ant 1

Channel 15 (6025MHz)

The Reference Level



The Mask Data



Channel 47 (6185MHz)

The Reference Level



The Mask Data



Channel 79 (6345MHz)

The Reference Level



The Mask Data



Channel 143 (6665MHz)


The Mask Data



802.11be-EHT320 – Ant 1

Channel 31 (6105MHz)

The Reference Level




The Mask Data



802.11be-EHT320 – Ant 1

Channel 63 (6265MHz)

The Reference Level



The Mask Data

