





Antenna Location

NB Mode




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)		
Right-Edge (Edge2)		
Bottom-Edge (Edge3)		
Left-Edge (Edge4)		
Rear Surface	9.2	9.2




Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	15	15
Right-Edge (Edge2)	310	4
Bottom-Edge (Edge3)	170	170
Left-Edge (Edge4)	4	310
Rear Surface	3	3

Stand Mode



Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	15	15
Right-Edge (Edge2)	310	4
Bottom-Edge (Edge3)	170	170
Left-Edge (Edge4)	4	310
Rear Surface	3	3

Tent Mode



Separation Distance (mm)	Wi-Fi Antenna (Main)	Wi-Fi Antenna (Aux)
Top-Edge (Edge1)	15	15
Right-Edge (Edge2)		
Bottom-Edge (Edge3)		
Left-Edge (Edge4)		
Rear Surface		


SETUP PHOTOS



NB Mode_Bottom



Tablet Mode_Rear




Tablet Mode_Edge1




Tablet Mode_Edge4



Tablet Mode_Edge2



Tent Mode_Edge1



Stand Mode_Rear



Stand Mode_Edge1



Stand Mode_Edge4




Stand Mode_Edge2

Test Mode Photos

NB Mode



Tablet Mode



Stand Mode



Tent Mode



EUT Photos

