



Bluetooth Earphone



HD
HD Voice Ready
Built-in Microphone

USER MANUAL


PRODUCT OVERVIEW



CHARGING EARBUDS

These earbuds have an internal rechargeable battery. The battery must be fully charged prior to use. Charging time is approximately 2 hrs. Your earbuds cannot be used while charging.

Red light ON – Charging Blue light ON – Fully charged



PAIRING EARBUDS TO BLUETOOTH DEVICE

Make sure the Bluetooth function is available on your electronic device. Specific pairing procedures may vary slightly depending on the device. For detailed information, please refer to your device's User Guide.

- If no device connection is made within 10 minutes of the earbuds being switched on, the earbuds will automatically switch off to save power.
- After successful pairing, devices will remember each other. When turned on, no pairing will be needed next time. If reconnection failed, please follow Bluetooth step-by-step pairing instructions to reconnect.

PAIRING TO BLUETOOTH DEVICE (CONTINUED):

1. Keep the distance between the device and the tzumi earbuds within 3 feet (for pairing only).
2. Press and hold the multi-function button for a couple of seconds until you hear prompt "Power on" and see blue light flash.
3. The device will go into pairing mode automatically until you hear prompt "Pairing" or see red and blue lights flash alternately.
4. Activate the Bluetooth function on your device to search for Bluetooth devices. Look for and select "Tzumi-Earbuds" in device list displayed.
5. After successful connection, you will hear voice prompt "Connected." The blue lights will flash quickly every few seconds. Earbuds are now ready for use.

EARBUDS CONTROLS

Making and receiving calls

- ANSWER/END CALL _____ Quickly press
- REJECT CALL _____ Quickly press 2 times
- REDIAL LAST CALL _____ Quickly press 2 times

3

Listening to Music

- Play/Pause/Resume music _____ Short Press
- Go to next song _____ Press and hold
- Go to previous song _____ Press and hold
- Power ON _____ Press and hold for 2 seconds
- Power OFF _____ Press and hold for 5 seconds
- Activate/Stop SIRI or Google Assistant during Standby/Music playing _____ Press for 1 second
- Disconnect current Bluetooth connection _____ Press and hold for 3 seconds

Changing the Volume

- Volume up _____ Short Press
- Volume down _____ Short Press

FAQ / Troubleshooting

- Q: Why do earbuds not turn on?**
A: Make sure earbuds are fully charged before using it for the first time. Your device can not be turned on if battery level is very low. Refer to Charging the Earbuds section of the manual.
- Q: There is no sound during playback.**
A: Check the Bluetooth connection between the earbuds and your device. If connection is not established, please reconnect again and adjust volume level as needed.

4

SPECIFICATIONS

Bluetooth Version	Bluetooth V4.2
Distance	up to 33ft (10m)
Battery	Rechargeable Lithium Battery: 80mAh
Frequency	20Hz-20kHz
Standby Time	Up to 120 hours
Charging Time	2 hours
Talk Time	up to 6 hours
Play Time	up to 5 hours (maximum volume)
Input	80mAh / 5V
Output	12mW

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

5