

Thank you for choosing the HUAWEI S10-D01  
LAPTOP DOCKING (dock for short).

## Dock at a Glance



No.	Item
1	Hinge
2	USB port
3	Keyboard
4	Buffer
5	HUAWEI MediaPad Dock Connector
6	Touchpad
7	Hinge lock
8	USB port




The HUAWEI MediaPad Dock Connector of NO.5 can be used to charge.

## Functional Keys

The laptop dock provides the following functional keys to facilitate your operations:

	Return		Enable or disable Wi-Fi
	Switch between Chinese and English input methods		Reduce the screen brightness
	Increase the screen brightness		Mute or unmute the speaker
	Reduce the volume		Increase the volume
	Rewind		Play or pause
	Fast forward		Display recently used applications
	Switch LCD display		Search
	Open or close the Camera application		Enable or disable Bluetooth
	Lock the screen		Touchpad
	Return to the home screen		Take a screenshot

## Installing HUAWEI MediaPad 10 FHD




1. Rotate the hinge by 60 to 120 degrees to make the dock's opening face upward.
2. Align HUAWEI MediaPad 10 FHD (MediaPad 10 for short) with the hinge.



Before you install MediaPad 10 to the dock, ensure that the hinge lock is set to the left, indicating that the hinge is unlocked.

3. Apply a gentle force to MediaPad 10 to install it on the hinge. When MediaPad 10 clicks into place, the hinge lock moves to the right, indicating that MediaPad 10 has been successfully installed to the dock.

## Removing HUAWEI MediaPad 10 FHD



When you move MediaPad 10 and the dock after installation, consider them as a whole and hold the bottom of the dock. Do not attempt to move them by grabbing MediaPad 10 only.

1. Use one hand to move the hinge lock to the left and fix the location of the dock.



Before you remove MediaPad 10, set the hinge lock to the left to unlock the hinge.

2. Use the other hand to move MediaPad 10 upward and remove it from the dock.



## Warnings and precautions:

1. This dock is designed for use with MediaPad 10 only.
2. Keep the dock clean.
3. Do not use the dock in a humid environment or expose it to humid air.
4. Protect the dock from steam generated by electrical products, such as a rice cooker or kettle.
5. Do not expose the dock to direct sunlight for too long, for example, do not place it in a car in direct sunlight.
6. Do not place the dock next to magnetic materials.
7. Do not place the dock on an unstable surface in case it drops.
8. Do not place heavy objects on the dock.
9. Protect the dock from violent shaking or bumps. Use a backpack with a buffering cushion to carry the dock. Do not place too many objects in the backpack to avoid damage to the dock.
10. Do not spill liquids or food scraps on the dock.
11. Keep your hands dry while using the dock to protect the dock from water damage.
12. During a flight, do not use the dock while the airplane is taking off or landing.
13. Do not use the dock near medical equipment in case it interferes with the equipment.
14. If the power cable or plug is damaged, stop using the dock and contact technical support personnel.
15. Before you clean the dock, power off MediaPad 10, and disconnect it from the power supply.
16. Use a slightly damp cloth (if possible, use a cleansing cloth dedicated for laptop computers) to clean the plastic parts of the dock. Do not use coarse or corrosive objects such as chemical cleaners or aerosols.
17. Do not forcibly remove MediaPad 10 from the dock without first unlocking the hinge.

18. Do not forcibly install MediaPad 10 to the dock before aligning them.

## **FCC STATEMENT**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - 1) This device may not cause harmful interference.
  - 2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**Copyright © Huawei Technologies Co., Ltd. 2012. All rights reserved.**

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd. The product described in this manual may include copyrighted software of Huawei Technologies Co., Ltd. and possible licensors. Customers shall not in any manner reproduce, distribute, modify, decompile, disassemble, decrypt, extract, reverse engineer, lease, assign, or sublicense the said software, unless such restrictions are prohibited by applicable laws or such actions are approved by respective copyright holders under licenses.

## **Trademarks and Permissions**



**HUAWEI**, **HUAWEI**, and



are trademarks or registered trademarks of Huawei Technologies Co., Ltd.

Other trademarks, product, service and company names mentioned are the property of their respective owners.

## **Notice**

Some features of the product and its accessories described herein rely on the software installed, capacities and settings of local network, and may not be activated or may be limited by local network operators or network service providers. Thus the descriptions herein may not exactly match the product or its accessories you purchase.

Huawei Technologies Co., Ltd. reserves the right to change or modify any information or specifications contained in this manual without prior notice or obligation.

## **NO WARRANTY**

THE CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO CASE SHALL HUAWEI TECHNOLOGIES CO., LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOST PROFITS, BUSINESS, REVENUE, DATA, GOODWILL OR ANTICIPATED SAVINGS.

## **Import and Export Regulations**

Customers shall comply with all applicable export or import laws and regulations and will obtain all necessary governmental permits and licenses in order to export, re-export or import the product mentioned in this manual including the software and technical data therein.

Issue: 01 (2012-07-30) Part Number: 96721430