



SISO MODE

802.11b
2412MHz Ant0




2437MHz Ant0




2462MHz Ant0




802.11g 2412MHz Ant0




2437MHz Ant0



2462MHz Ant0




802.11n-HT20
2412MHz Ant0




2437MHz Ant0




2462MHz Ant0




802.11n-HT40 2422MHz Ant0



2437MHz Ant0




2452MHz Ant0




MIMO MODE (2 TX, Ant0+Ant1 or Ant1+Ant2 or Ant0+Ant2)


802.11n-HT20
2412MHz Ant0




2412MHz Ant1




2412MHz Ant2




2437MHz Ant0




2437MHz Ant1




2437MHz Ant2




2462MHz Ant0




2462MHz Ant1




2462MHz Ant2




802.11n-HT40 2422MHz Ant0




2422MHz Ant1




2422MHz Ant2




2437MHz Ant0




2437MHz Ant1




2437MHz Ant2




2452MHz Ant0



2452MHz Ant1




2452MHz Ant2




MIMO MODE (3 TX, Ant0+Ant1+Ant2)


802.11n-HT20
2412MHz Ant0




2412MHz Ant1




2412MHz Ant2




2437MHz Ant0




2437MHz Ant1




2437MHz Ant2




2462MHz Ant0




2462MHz Ant1




2462MHz Ant2




802.11n-HT40 2422MHz Ant0




2422MHz Ant1




2422MHz Ant2




2437MHz Ant0




2437MHz Ant1




2437MHz Ant2



2452MHz Ant0



2452MHz Ant1



2452MHz Ant2

